



**A Part Of
Something
Better™**

ERP



TABLE OF CONTENTS

COOKING

Appliance Bulbs.....	2
Bake and Broil Elements.....	2-6
BBQ Igniters	9
Burners.....	6-7
Burner Caps	7
Burner Valve.....	7
Door Handles.....	7
Drip Pans	7-8
Filters.....	8-9
Grates	9
Igniters	9-11
Infinite Switches.....	11-13
Knobs.....	14-17
Knob Kits	17
Motors	17
Oven Control Boards	18
Oven Door Gaskets.....	18
Oven Pilots	18
Oven Racks	18-19
Oven Sensors.....	19-20
Paints.....	20
Pressure Regulators.....	20
Safety Valves.....	20-21
Spark Modules	21-22
Surface Elements.....	22-27
Terminal Blocks.....	27
Thermal Fuses	27
Thermostats.....	28-29

DISHWASHER

Door Springs	30
Element	30
Gaskets.....	30-31
Pumps.....	32-33
Rack	33
Rollers	33-34
Spray Arms.....	34
Thermal Fuses	34-35
Thermostat.....	35
Water Valves.....	35-36

DRYER

Belts.....	37-38
Blower Wheels.....	38
Coil Kits.....	38
Door Switches	38-39
Drum Bearings.....	39
Drum Glides	39
Elements.....	40-41
Felts	41
Idler Pulleys	41-42
Igniters.....	42-43
Knobs.....	43-44
Lint Filter/Screens	44-45
Motor.....	45

Rollers.....	45-46
Thermal Fuses	47-48
Thermistors	48
Thermostats.....	48-49
Timers.....	49

HVAC

Flame Sensors	50
Furnace Igniters.....	50-51
Ignition Modules.....	51
Motors	51
Super Seal.....	51-52

MICROWAVE

Bulbs	53
Capacitors.....	53
Fuses/Diodes.....	53-54
Door Handles.....	54
Magnetrons	54-55
Switches.....	56
Turntable Trays	56

REFRIGERATION

Bin	57
Capacitors.....	57
Cold Controls	57-58
Defrost Heaters	58-59
Defrost Timers.....	59-60
Defrost Thermostats.....	60-62
Door Bars	62
Door Gaskets	62-65
Handles	66
Ice Makers.....	66-67
Motors	68-72
Overloads/Relays.....	72
Spun Copper Driers.....	73
Temperature Sensors.....	73-74
Thermistors.....	74
Water Filters	74-75
Water Valves.....	75-78

WASHER

Actuators.....	79
Belts.....	80-81
Couplers	81
Door Boots	81-82
Hoses	82-83
Knobs.....	83
Latches	83
Lid Switches	83-84
Locks	84-85
Pressure Switches	85-86
Pumps.....	86-88
Shock Absorbers.....	89
Suspension Rods/Kits.....	90
Water Valves.....	91-95



Part No. **WB2X7909**
Anti-Tip Kit
 51-1/2" chain length
 Replacement for GE



Part No. **10C7**
Appliance Bulb
 130V, 10 watt
 Candelabra base




Part No. **40A15**
Appliance Bulb
 120V, 40 watt
 Medium base



Part No. **40T61/2**
Appliance Bulb
 120V, 40 watts
 Intermediate base

Measurement Key for Elements




A = Measurement between terminals
 B = Measurement between terminal end & mounting bracket
 C = Measurement between mounting bracket and end of element
 D = Measurement of element width



A = 13"
 B = 3-3/4"
 C = 15"
 D = 19-1/4"

Part No. **B775**
Bake Element
 Watts: 2400/1800 Volts: 240/208
 Has .250" male terminal push-in connection



A = 1-3/4"
 B = 3-1/4"
 C = 14-3/4"
 D = 19-3/4"

Part No. **B777**
Bake Element
 Watts: 2750/2065 Volts: 240/208
 Has .250" male terminal push-in connection




A = 12-1/8"
 B = 3"
 C = 15"
 D = 15-3/4"

Part No. **B778**
Bake Element
 Watts: 2100/1577 Volts: 240/208
 Has .250" male terminal push-in connection




A = 1-3/4"
 B = 3"
 C = 15-3/4"
 D = 16-5/8"

Part No. **B790**
Bake Element
 Watts: 2600/1950 Volts: 240/208
 Has .250" male terminal push-in connection




A = 14"
 B = 3-1/4"
 C = 15-5/8"
 D = 19-1/8"

Part No. **B837**
Bake Element
 Watts: 2400 Volts: 240
 Has .250" male terminal push-in connection



A = 1-3/4"
 B = 2"
 C = 16"
 D = 16"

Part No. **B856**
Bake Element
 Watts: 2750/2065 Volts: 240/208
 Has .250" male terminal push-in connection



A = 19"
 B = 3-1/4"
 C = 15-1/4"
 D = 19"


Part No. **B0750**
Bake Element
 Watts: 2585/1939 Volts: 240/208
 Has .250" male terminal push-in connection



A = 2"
B = 3"
C = 13-3/8"
D = 15-1/8"

Part No. **B1094**
Bake Element


Watts: 2500 Volts: 240
Has .250" male terminal push-in connection



A = 2"
B = 3-5/8"
C = 15"
D = 18-1/4"

Part No. **B1117**
Bake Element


Watts: 3600 Volts: 240
Has .250" male terminal push-in connection



A = 12-5/8"
B = 4"
C = 15-3/4"
D = 17-3/8"

Part No. **B2200**
Bake Element


Watts: 3500 Volts: 240
Has .250" male terminal push-in connection



A = 13-1/2"
B = 2-3/8"
C = 14-7/8"
D = 13-1/2"

Part No. **B2395**
Bake Element


Watts: 2000 Volts: 250
Has .250" male terminal push-in connection



A = 14"
B = 3"
C = 15-3/4"
D = 14-1/4"

Part No. **B3800**
Bake Element


Watts: 3500 Volts: 240
Has .250" male terminal push-in connection



A = 2"
B = 3-1/4"
C = 15-3/8"
D = 18-7/8"

Part No. **B4107**
Bake Element


Watts: 2585/1939 Volts: 240/208
Has .250" male terminal push-in connection



A = 2-1/4"
B = 4"
C = 15-1/2"
D = 20-1/8"

Part No. **B5002**
Bake Element


Watts: 3000 Volts: 240
Has .250" male terminal push-in connection



A = 16-1/8"
B = 3-3/8"
C = 14-3/4"
D = 19-1/4"

Part No. **B5103**
Bake Element


Watts: 2600 Volts: 240
Has .250" male terminal push-in connection



A = 13"
B = 3-1/2"
C = 15-7/8"
D = 15-5/8"

Part No. **B5900**
Bake Element


Watts: 3500 Volts: 240
Has .250" male terminal push-in connection



A = 19-1/2"
B = 3-1/2"
C = 15-1/4"
D = 19-1/2"

Part No. **B7019**
Bake Element


Watts: 2800/2100 Volts: 240/208
Has .250" male terminal push-in connection



A = 21-1/2"
B = 2-1/4"
C = 16-1/4"
D = 21-1/2"

Part No. **B7646**
Bake Element

Watts: 2600 Volts: 240
Has .250" male terminal push-in connection




A = 2-1/8"
B = 2-1/2"
C = 15-1/4"
D = 20-3/8"


Part No. **B8541**
Bake Element

Watts: 2400/1800 Volts: 240/208
Has .250" male terminal push-in connection

Measurement Key for Elements



- A = Measurement between terminals
- B = Measurement between terminal end & mounting bracket
- C = Measurement between mounting bracket and end of element
- D = Measurement of element width




- A = 21"
- B = 1-7/8"
- C = 17-3/4"
- D = 21"

Part No. **DG47-00038B**

Bake Element

Watts: 2400 Volts: 240
Has .250" male terminal push-in connection




- A = 2-1/2"
- B = 2-1/2"
- C = 16-1/2"
- D = 20"

Part No. **MEE36593202**

Bake Element

Watts: 3400 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-1/2"
- C = 16-1/2"
- D = 14"

Part No. **MEE62306504**

Bake Element

Watts: 4200 Volts: 240
Has .250" male terminal push-in connection




- A = 2"
- B = 1-3/8"
- C = 15-1/4"
- D = 14-5/8"

Part No. **W10207397**

Bake Element

Watts: 2000 Volts: 240
Has .250" male terminal push-in connection




- A = 2"
- B = 3-1/2"
- C = 16-1/2"
- D = 20-1/2"

Part No. **W10779716**

Bake Element

Watts: 3800 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 4"
- C = 16"
- D = 17"

Part No. **WB44K5012**

Bake Element

Watts: 2850 Volts: 240
Has .250" male terminal push-in connection




- A = 1-3/4"
- B = 3"
- C = 16"
- D = 13-3/4"

Part No. **WB44K5013**

Bake Element

Watts: 2000 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-1/2"
- C = 15-1/4"
- D = 17-3/4"

Part No. **WB44K10005**

Bake Element

Watts: 2585 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-3/4"
- C = 17"
- D = 18"

Part No. **WB44T10010**

Bake Element

Watts: 2585 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-1/4"
- C = 16-7/8"
- D = 17-3/4"

Part No. **WB44T10011**

Bake Element

Watts: 3410 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-5/8"
- C = 16-3/8"
- D = 18-7/8"

Part No. **WB44T10014**

Bake Element

Watts: 3800 Volts: 240
Has .250" male terminal push-in connection




A = 1-7/8"
B = 2-3/4"
C = 22-1/2"
D = 16-3/4"

Part No. **WB44T10104**

Bake Element

Watts: 2850 Volts: 240

Has .250" male terminal push-in connection




A = 1-1/4"
B = 2-1/2"
C = 16-1/4"
D = 13-3/8"

Part No. **WB44X200**

Bake Element

Watts: 3100/2330 Volts: 250/208

Has screw-in connection




A = 1-1/4"
B = 1-3/8"
C = 15"
D = 13-1/4"

Part No. **WB44X5043**

Bake Element

Watts: 3000 Volts: 250

Has screw-in connection




A = 1-1/4"
B = 2-1/2"
C = 14-3/4"
D = 17-5/8"

Part No. **WB44X5082**

Bake Element

Watts: 2585/1940 Volts: 250/208

Has screw-in connection




A = 1-1/4"
B = 1-1/2"
C = 16"
D = 17-3/4"

Part No. **WB44X5099**

Bake Element

Watts: 2585/1940 Volts: 250/208

Has screw-in connection




A = 1-3/4"
B = 3-1/4"
C = 15-1/2"
D = 18"

Part No. **WB44X10009**

Bake Element

Watts: 2585/1940 Volts: 240/208

Has .250" male terminal push-in connection




A = 1-1/2"
B = 3"
C = 15-1/2"
D = 18-5/8"

Part No. **WB44X10016**

Bake Element

Watts: 3410 Volts: 240

Has .250" male terminal push-in connection



A = 12"
C = 18-7/8"
D = 11-3/4"

Part No. **B779**

Broil Element

Watts: 3000/2250 Volts: 240/208

Has .250" male terminal push-in connection




A = 13"
B = 3-1/2"
C = 14-7/8"
D = 13"

Part No. **B1551**

Broil Element

Watts: 2100 Volts: 240

Has .250" male terminal push-in connection




A = 11-3/4"
B = 3-1/4"
C = 15-3/8"
D = 11-3/4"

Part No. **B3200**

Broil Element

Watts: 3000 Volts: 240

Has .250" male terminal push-in connection




A = 12-3/8"
B = 3-1/4"
C = 15-3/8"
D = 12-3/8"

Part No. **B3301**

Broil Element

Watts: 4000 Volts: 240

Has .250" male terminal push-in connection



A = 9"
B = 2-5/8"
C = 16-3/4"
D = 18-7/8"


Part No. **B7340**

Broil Element


Watts: 3400/2550 Volts: 240/208

Has .250" male terminal push-in connection

Measurement Key for Elements




- A = Measurement between terminals
- B = Measurement between terminal end & mounting bracket
- C = Measurement between mounting bracket and end of element
- D = Measurement of element width



- A = 1-1/2"
- B = 2-5/8"
- C = 15-5/8"
- D = 13-3/4"

Part No. **WB44K5009**
Broil Element


Watts: 3400 Volts: 240
 Has .250" male terminal push-in connection



- A = 1-3/4"
- B = 2-11/16"
- C = 16-7/8"
- D = 14"

Part No. **WB44K10002**
Broil Element


Watts: 3410 Volts: 240
 Has .250" male terminal push-in connection



- A = 1-1/4"
- B = 1-3/8"
- C = 15-1/2"
- D = 11-3/4"

Part No. **WB44X173**
Broil Element

Watts: 3400 Volts: 240
 Has screw-in connection



- A = 1-1/2"
- B = 2-1/2"
- C = 17"
- D = 11-3/4"

Part No. **WB44T10009**
Broil Element

Watts: 3410 Volts: 240
 Has .250" male terminal push-in connection



Part No. **3412A00419**
Burner (Double)

Replacement for Whirlpool



Part No. **74003332**
Burner (Double)

3-1/8" height • 15" length
 Replacement for Whirlpool



Part No. **WB16K10026**
Burner (Double)

3" height • 11-5/8" length
 Replacement for GE



Part No. **1398**
Burner (Front)

3-7/8" height • 8-1/8" length
 Replacement for Peerless



Part No. **1801M58**
Burner (Front)

2-3/4" height • 9-3/8" length
 Replacement for Brown



Part No. **316039002**
Burner (Front)

3-1/8" height • 7-5/8" length
 Replacement for Electrolux



Part No. **316103802**
Burner (Front)

3-1/8" height • 7-5/8" length
 Replacement for Electrolux



Part No. **1801M59**
Burner (Rear)
 4-1/2" height • 15-3/8" length
 Replacement for Brown



Part No. **316039003**
Burner (Rear)
 3-5/8" height • 13-3/4" length
 Replacement for Electrolux



Part No. **316103803**
Burner (Rear)
 3-5/8" height • 13-3/4" length
 Replacement for Electrolux



Part No. **DG62-00067A**
Burner Cap (Large)
 3-3/4" diameter
 Replacement for Samsung



Part No. **DG62-00070A**
Burner Cap (Medium)
 2-5/8" diameter
 Replacement for Samsung



Part No. **DG62-00111A**
Burner Cap (Small)
 1-5/8" diameter
 Replacement for Samsung



Part No. **W10141709**
Burner Valve
 270° shaft rotation, saddle mount
 Replacement for Whirlpool



Part No. **316270200**
Door Handle
 29" length x 1-3/8" wide
 Replacement for Electrolux



Part No. **316270201**
Door Handle
 29" length x 1-3/8" wide
 Replacement for Electrolux



Part No. **DB6GE1**
Drip Pan (6")



Part No. **DB6GE2**
Drip Pan (6")



Part No. **DB6WH**
Drip Pan (6")



Part No. **DBU6**
Drip Pan (6")



Part No. **DBU6P**
Drip Pan (6")



Part No. **DBU6P1**
Drip Pan (6")



Part No. **DB8GE1**
Drip Pan (8")



Part No. **DB8GE2**
Drip Pan (8")



Part No. **DB8WH**
Drip Pan (8")



Part No. **DBU8**
Drip Pan (8")



Part No. **DBU8P**
Drip Pan (8")



Part No. **DBU8P1**
Drip Pan (8")



Part No. **TR6GE**
Trim Ring (6")



Part No. **TR8GE**
Trim Ring (8")



Part No. **8504**
Filter (Aluminum Grease)
8-3/4" x 10-1/2", 3/32" thick



Part No. **ALTR012**
Filter (Aluminum Grease)
 5-1/8" x 7-5/8", 3/32" thick




Part No. **WB06X10596**
Filter (Aluminum Grease)
 5-7/8" x 13-3/8", 3/32" thick



Part No. **WB6X486**
Filter (Aluminum Grease)
 7-3/4" x 9", 3/32" thick



Part No. **WB02X10700**
Filter (Combination)
 9" x 10-1/2", 3/32" thick



Part No. **WB31K10012**
Grate
 8-1/2" x 8-1/2", 1-1/4" height
 Replacement for GE



Part No. **119-4400-5**
Igniter (BBQ)
 5 outlet
 Used on Amana, Brinkmann, Charmglow, Kenmore



Part No. **NEX200828**
Igniter (BBQ)
 6 outlet
 Used on Jenn-Air



Part No. **644424**
Igniter (Oven)
 8-1/2" lead wires
 1-1/2" ceramic block



Part No. **DG94-00520A**
Igniter (Oven)
 1-1/2" ceramic block



Part No. **DG94-01012A**
Igniter (Oven)
 One 8" & one 9-1/2" lead wires
 1-1/2" ceramic block



Part No. **GR403**
Igniter (Oven)
 12" lead wires




Part No. **IG0001**
Igniter (Oven)
 12" lead wires
 1-1/2" ceramic block





Part No. **IG21**
Igniter (Oven)
 8" lead wires
 1-1/2" ceramic block



Part No. **IG35**
Igniter (Oven)
 8" lead wires
 1-1/2" ceramic block



Part No. **IG5068**
Igniter (Oven)
 13" lead wires
 5-1/4" ceramic block



Part No. **IG5652**
Igniter (Oven)
 10" lead wires
 1-1/2" ceramic block



Part No. **IG9159**
Igniter (Oven)
 13" lead wires
 5-1/4" ceramic block



Part No. **IG9400**
Igniter (Oven)
 16" lead wires
 1-1/2" ceramic block




Part No. **IG9998**
Igniter (Oven)
 17" lead wires
 1-1/2" ceramic block



Part No. **IG10016**
Igniter (Oven)
 15", 12" & 8" lead wires
 1-1/2" ceramic block



Part No. **MEE61841401**
Igniter (Oven)
 11" lead wires
 1-1/2" ceramic block



Part No. **WB13K10043**
Igniter (Oven)
 17-3/4" lead wires
 1-3/8" ceramic block



Part No. **189324**
Igniter (Spark)
 Has .110" male terminal
 Replacement for Bosch



Part No. **8523793**
Igniter (Spark)
 Has .25" male terminal
 Replacement for Whirlpool



Part No. **9758079**

Igniter (Spark)

Has .110" male terminal
Replacement for Whirlpool



Part No. **W10209656**

Igniter (Spark)

29-1/2" lead wire with .110" female end
Replacement for Whirlpool



Part No. **W10209656KIT**

Igniter (Spark)

29-1/2" lead wire with .110" female end
Replacement for Whirlpool



Part No. **W10324262**

Igniter (Spark)

Has .110" male terminal
Replacement for Whirlpool



Part No. **W10278150**

Igniter Clip



Part No. **3148952**

Infinite Switch

Current sensing type
240V, 5.4 - 7.8 amp
Replacement for Whirlpool



Part No. **3148953**

Infinite Switch

Current sensing type
240V, 7.5 - 9.3 amp
Replacement for Whirlpool



Part No. **3149400**

Infinite Switch

Current sensing type
240V, 8.9 - 11 amp
Replacement for Whirlpool



Part No. **3149404**

Infinite Switch

Current sensing type
240V, 5.2 - 6.6 amp
Replacement for Whirlpool



Part No. **5500200**

Infinite Switch

Voltage sensing type, 240V, 13 amp
Includes square breakoff shaft with multiple nylon
adapter inserts for virtually all knobs used by
Electrolux, GE, Maytag, Whirlpool & others



Part No. **5500200M**

Infinite Switch

Voltage sensing type, 240V, 13 amp
Includes square breakoff shaft with multiple nylon
adapter inserts for virtually all knobs used by
Electrolux, GE, Maytag, Whirlpool & others



Part No. **5500202M**

Infinite Switch

Voltage sensing type, 240V, 13 amp
Includes square breakoff shaft with multiple nylon
adapter inserts for virtually all knobs used by
Electrolux, GE, Maytag, Whirlpool & others



Part No. **5502404**
Infinite Switch
 Voltage sensing type
 240V, 15 amp



Part No. **316238201**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for Electrolux



Part No. **316238202**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for Electrolux



Part No. **316436000**
Infinite Switch
 Current sensing type
 240V, 5.2 - 6.25 amp
 Replacement for Electrolux



Part No. **316436001**
Infinite Switch
 Current sensing type
 240V, 8.8 - 10.8 amp
 Replacement for Electrolux



Part No. **7403P23960**
Infinite Switch
 Current sensing type
 240V, 8.9 - 11 amp
 Replacement for Whirlpool



Part No. **807004702**
Infinite Switch
 240V
 Replacement for Whirlpool



Part No. **DG44-01002A**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for Samsung



Part No. **DG44-01008A**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for Samsung



Part No. **DG44-01009A**
Infinite Switch
 Current sensing type
 240V, 4.4 - 5.8 amp
 Replacement for Samsung



Part No. **W10434452**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for Whirlpool



Part No. **W10857622**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for Whirlpool



Part No. **WB23K5027**
Infinite Switch
 Current sensing type
 240V, 8.9 - 11 amp
 Replacement for GE



Part No. **WB23M24**
Infinite Switch
 Current sensing type
 240V, 5.2 - 6.6 amp
 Replacement for GE



Part No. **WB24T10022**
Infinite Switch
 Current sensing type
 240V, 4.4 - 5.8 amp
 Replacement for GE



Part No. **WB24T10025**
Infinite Switch
 Current sensing type
 240V, 8.9 - 11 amp
 Replacement for GE



Part No. **WB24T10027**
Infinite Switch
 Current sensing type
 240V, 7.5 - 9.3 amp
 Replacement for GE



Part No. **WB24T10029**
Infinite Switch
 Current sensing type
 240V, 4.4 - 7.4 amp
 Replacement for GE



Part No. **WB24T10058**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for GE



Part No. **WB24T10063**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for GE



Part No. **WB24T10119**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for GE



Part No. **WB24T10153**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for GE



Part No. **WB24T10162**
Infinite Switch
 Voltage sensing type
 240V
 Replacement for GE



Part No. **WB24X25013**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for GE



Part No. **6286W**

Knob (Burner)

Flush shaft

Replacement for Peerless Premier

"D" position



Part No. **7737P245-60**

Knob (Burner)

1/2" extended shaft

Replacement for Whirlpool

"D" position



Part No. **3181304**

Knob (Burner)

3/4" extended shaft

Replacement for Whirlpool

"D" position



Part No. **8273106**

Knob (Burner)

1/8" extended shaft

Replacement for Whirlpool

"D" position



Part No. **71001641**

Knob (Burner)

5/8" extended shaft

Replacement for Whirlpool

"D" position



Part No. **74007733**

Knob (Burner)

1/4" extended shaft

Replacement for Whirlpool

"D" position



Part No. **74010205**

Knob (Burner)

1/4" extended shaft

Replacement for Whirlpool

"D" position



Part No. **74010839**

Knob (Burner)

1/4" extended shaft

Replacement for Whirlpool

"D" position



Part No. **74011260**

Knob (Burner)

1/2" extended shaft

Replacement for Whirlpool

"D" position



Part No. **74011287**

Knob (Burner)

1/4" extended shaft

Replacement for Whirlpool

"D" position



Part No. **316220000**

Knob (Burner)

3/8" extended shaft

Replacement for Electrolux

"D" position



Part No. **316220008**

Knob (Burner)

3/8" extended shaft

Replacement for Electrolux

"D" position





Part No. **316220009** "D" position
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

.256



Part No. **316353104** "D" position
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

.256



Part No. **316543907** "D" position
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

.256



Part No. **316564509** "D" position
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

.340



Part No. **318099104** "D" position
Knob (Burner)
 1/2" extended shaft
 Replacement for Electrolux

.340



Part No. **5304507386** "D" position
Knob (Burner)
 1/2" extended shaft
 Replacement for Electrolux

.340



Part No. **5304509929** "D" position
Knob (Burner)
 1/2" extended shaft
 Replacement for Electrolux

.340



Part No. **EBZ37189609** "D" position
Knob (Burner)
 1/4" extended shaft
 Replacement for LG

.256



Part No. **EBZ37189611** "D" position
Knob (Burner)
 1/4" extended shaft
 Replacement for LG

.256



Part No. **W10339442** "D" position
Knob (Burner)
 1/8" extended shaft
 Replacement for Whirlpool

.256



Part No. **W10370189** "D" position
Knob (Burner)
 1/8" extended shaft
 Replacement for Whirlpool

.256



Part No. **W10766544** "D" position
Knob (Burner)
 1/8" extended shaft
 Replacement for Whirlpool

.256



Part No. **W10836470**

Knob (Burner)

1/8" extended shaft
Replacement for Whirlpool

"D" position



Part No. **WB03K10216**

Knob (Burner)

3/8" extended shaft
Replacement for GE

"D" position



Part No. **WB03K10265**

Knob (Burner)

1-3/8" extended shaft
Replacement for GE

"D" position



Part No. **WB03K10303**

Knob (Burner)

1/2" extended shaft
Replacement for GE

"D" position



Part No. **WB03K10305**

Knob (Burner)

1/8" extended shaft
Replacement for GE

"D" position



Part No. **WB03T10325**

Knob (Burner)

3/8" extended shaft
Replacement for GE

"D" position



Part No. **WB3X712**

Knob (Burner)

5/8" extended shaft
Replacement for GE

"D" position



Part No. **Y700854**

Knob (Burner)

Flush shaft
Replacement for Whirlpool

"D" position



Part No. **316102303**

Knob (Thermostat)

Flush shaft
Replacement for Whirlpool

"D" position



Part No. **WB03K10036**

Knob (Thermostat)

1/2" extended shaft
Replacement for GE

"D" position



Part No. **WB03K10159**

Knob (Thermostat)

1/2" extended shaft
Replacement for GE

"D" position



Part No. **WB03K10187**

Knob (Thermostat)

1/8" extended shaft
Replacement for GE

"D" position





Part No. **WB03K10202** "D" position
Knob (Thermostat)
 Flush shaft
 Replacement for GE



Part No. **WB03K10302** "D" position
Knob (Thermostat)
 1/8" extended shaft
 Replacement for GE



Part No. **KN001**
Knob Kit (Universal Gas)
 Kit includes: (5) knobs, (4) burner inlays,
 (1) thermostat inlay, (5) black inserts,
 (5) white inserts



Part No. **KN002**
Knob Kit (Universal Electric)
 Kit includes: (5) knobs, (8) burner inlays,
 (2) thermostat inlays, (5) blue inserts,
 (5) gray inserts, (5) green inserts,
 (5) red inserts, (5) yellow inserts



Part No. **W10698166**
Knob Kit (Burner)
 Kit includes: (5) knobs
 Replacement for Whirlpool



Part No. **W10762263**
Knob Kit (Burner)
 Kit includes: (5) knobs
 Replacement for Whirlpool



Part No. **WB03X23020**
Knob Kit (Burner)
 Kit includes: (5) knobs
 Replacement for GE



Part No. **W10490648**
Mixer Beaters (Pair)
 Replacement for Whirlpool



Part No. **DG31-00005A**
Motor (Convection)
 Replacement for Samsung



Part No. **97012038**
Motor (Vent Hood)
 Replacement for Broan




Part No. **97012248**
Motor (Vent Hood)
 Replacement for Broan, GE




Part No. **M550**
Motor (Vent Hood)
 0.55 amps, 3000 RPM
 1-3/4" shaft, CCW Rotation



Part No. **W10380496**
Motor Brush
 Replacement for Whirlpool



Part No. **5304518660**
Oven Control Board
 Used on electric oven
 Replacement for Electrolux



Part No. **5304518661**
Oven Control Board
 Used on gas oven
 Replacement for Electrolux



Part No. **316239700**
Oven Door Gasket
 50-1/2", 12 mounting clips
 Replacement for Electrolux



Part No. **7212P043-60**
Oven Door Gasket
 52", 12 mounting clips
 Replacement for Whirlpool



Part No. **WB2X1522**
Oven Door Gasket
 64-1/4"
 Replacement for GE



Part No. **WB32K3**
Oven Door Gasket
 54", 16 mounting clips
 Replacement for GE



Part No. **74010141**
Oven Pilot
 Standing pilot
 Replacement for Whirlpool



Part No. **WB19K10008**
Oven Pilot
 Standing pilot
 Replacement for GE



Part No. **4334809**
Oven Rack
 22-3/8" wide
 16-1/8" deep
 Replacement for Whirlpool



Part No. **316067902**
Oven Rack
 22-13/16" wide
 16-1/8" deep
 Replacement for Electrolux



Part No. **316496201**
Oven Rack
 24-1/4" wide
 15-7/8" deep
 Replacement for Electrolux






Part No. **W10256908**

Oven Rack

24" wide
16" deep

Replacement for Whirlpool



Part No. **W10282492**

Oven Rack

22-7/8" wide
17-1/4" deep

Replacement for Whirlpool



Part No. **WB48T10011**

Oven Rack

24-1/8" wide
18" deep

Replacement for GE



Part No. **WB48T10063**

Oven Rack

24-1/4" wide
16-7/8" deep

Replacement for GE



Part No. **WB48T10095**

Oven Rack

23-3/4" wide
17-1/2" deep

Replacement for GE



Part No. **WB48X5099**

Oven Rack

22-7/8" wide
16" deep

Replacement for GE



Part No. **12001655**

Oven Sensor

2" long probe, includes two optional wires
Fits most applications

Replacement for Whirlpool



Part No. **12001656**

Oven Sensor

6" long probe, includes two optional wires
Fits most applications

Replacement for Whirlpool



Part No. **316217002**

Oven Sensor

3-1/4" long probe

Replacement for Electrolux



Part No. **316233902**

Oven Sensor

3-1/4" long probe

Replacement for Electrolux



Part No. **DG32-00002B**

Oven Sensor

2-3/4" long probe

Replacement for Samsung




Part No. **W10131825**

Oven Sensor

3" long probe

Replacement for Whirlpool

COOKING



Part No. **W10181986**
Oven Sensor
 6" long probe
 Replacement for Whirlpool



Part No. **WB23X5340**
Oven Sensor
 2-1/8" long probe
 Replacement for GE



Part No. **1126**
Paint (Touch Up)
 White



Part No. **1438**
Paint (Touch Up)
 Almond



Part No. **1440**
Paint (Touch Up)
 Bisque



Part No. **1999**
Paint (Touch Up)
 Black



Part No. **316091706**
Pressure Regulator 
 1/2" x 1/2" NPT
 4"/10" convertible, Set at 4" natural gas
 Includes shut-off valve
 Replacement for Electrolux



Part No. **PR1**
Pressure Regulator 
 1/2" x 1/2" NPT
 4"/10" convertible



Part No. **PR2**
Pressure Regulator 
 1/2" x 1/2" NPT
 5"/10" convertible



Part No. **PR4**
Pressure Regulator 
 3/4" x 3/4" NPT
 4"/10" convertible



Part No. **DG94-00449A**
Safety Valve & Pressure Regulator Assembly



Part No. **1802A206**
Safety Valve
 3/8" Inlet, includes mounting bracket
 Replacement for Brown


COOKING



Part No. **56120**
Safety Valve
 Replacement for Atwood



Part No. **3203459**
Safety Valve
 Replacement for Electrolux



Part No. **5817S0007**
Safety Valve
 Universal Kit
 Replaces 90% of all 5817 series safety valves



Part No. **WB19K12**
Safety Valve
 3/8" Inlet, includes mounting bracket
 Replacement for GE




Part No. **WB19K31**
Safety Valve
 1/4" female terminals
 Replacement for GE



Part No. **6513S0001**
Spark Module
 2+1 (2 manual circuits for top burner ignition & 1 flame sensing circuit for automatic oven reignition)
 Has (6) .250" & (3) .110" male terminals



Part No. **6520S0201**
Spark Module
 2+0 (2 manual circuits for top burner ignition & no oven ignition circuit)
 Universal split terminal design suitable for: .110", .187" & .250" push on wiring



Part No. **6540S0001**
Spark Module
 0+4 (No manual circuits for top burner ignition, all 4 top burner circuits are individual flame sensing for automatic top burner reignition)
 Has (7) .250" & (4) .110" male terminals



Part No. **6544S0001**
Spark Module
 4+0 (4 manual circuits for top burner ignition & no oven ignition circuit)
 Snap in mounting
 Has (2) .250" & (4) .187" male terminals



Part No. **6545S0001**
Spark Module
 2+0 (2 manual circuits for top burner ignition & no oven ignition circuit)
 Snap in mounting
 Has (2) .250" & (2) .187" male terminals



Part No. **6547S0001**
Spark Module
 4+1 (4 manual circuits for top burner ignition & 1 flame sensing circuit for automatic oven reignition)
 Has (6) .250" & (5) .110" male terminals



Part No. **6549S0001**
Spark Module
 2+1 (2 manual circuits for top burner ignition & 1 flame sensing circuit for automatic oven reignition)
 Has (6) .250" & (3) .110" male terminals



Part No. **6610341**

Spark Module

4+0 (4 manual circuits for top burner ignition & no oven ignition circuit)
Has (2) .250" & (4) .110" male terminals
Replacement for Whirlpool



Part No. **12001596**

Spark Module

4+0 (4 manual circuits for top burner ignition & no oven ignition circuit)
Has (2) .250" & (4) .110" male terminals
Replacement for Whirlpool



Part No. **7431P2760K**

Spark Module

4+0 (4 manual circuits for top burner ignition & no oven ignition circuit) Snap in mounting
Has (2) .250" & (4) .110" male terminals
Replacement for Whirlpool



Part No. **808608801**

Spark Module

2+0 (2 manual circuits for top burner ignition & no oven ignition circuit)
Has (1) .250", (1) .187" & (2) .110" male terminals
Replacement for Whirlpool



Part No. **808608802**

Spark Module

4+0 (4 manual circuits for top burner ignition & no oven ignition circuit)
Has (1) .250", (1) .187" & (4) .110" male terminals
Replacement for Whirlpool



Part No. **PA020047**

Spark Module

0+4 (No manual circuits for top burner ignition, all 4 top burner circuits are individual flame sensing for automatic top burner reignition)
Replacement for Viking



Part No. **W10110486**

Spark Module

Has (3) .250" & (6) .110" male terminals
Replacement for Whirlpool



Part No. **W10110491**

Spark Module

Has (3) .250" & (4) .110" male terminals
Replacement for Whirlpool



Part No. **WB13T10076**

Spark Module

Has (5) .110" male terminals
Replacement for GE



Part No. **W10331686**

Spark Module Circuit Board

This board has diagnostic capabilities to help diagnose problems that may occur in your range. The LED light on your board will blink different codes, whose meanings are printed on the board.
Replacement for Whirlpool



Part No. **WB24T10071**

Spark Switch

Has a .256" "D" insert
Replacement for GE



Part No. **S30M1**

Surface Element

6"- 5 Turn
1000W@208V 1325W@240V
Replacement for GE



Part No. **S30M2**
Surface Element
8"- 6 Turn
1765W@208V 2350W@240V
Replacement for GE



Part No. **S36Y12**
Surface Element
6"- 3 Turn
1250W@240V



Part No. **S46D15**
Surface Element
6"- 4 Turn
1500W@240V



Part No. **S46Y12**
Surface Element
6"- 4 Turn
1250W@240V



Part No. **S46Y15**
Surface Element
6"- 4 Turn
1500W@240V



Part No. **S48D21**
Surface Element
8"- 4 Turn
2100W@240V



Part No. **S48Y21**
Surface Element
8"- 4 Turn
2100W@240V



Part No. **S58D21**
Surface Element
8"- 5 Turn
2100W@240V



Part No. **S58D26**
Surface Element
8"- 5 Turn
2600W@240V



Part No. **S58Y21**
Surface Element
8"- 5 Turn
2100W@240V



Part No. **S58Y26**
Surface Element
8"- 5 Turn
2600W@240V



Part No. **S218**
Surface Element
6"- 5 Turn
1000W@208V 1325W@240V
Replacement for GE



Part No. **S219**
Surface Element
8"- 6 Turn
1765W@208V 2350W@240V
Replacement for GE



Part No. **S348**
Surface Element
8"- 6 Turn
1765W@208V 2350W@240V
Replacement for GE



Part No. **S354**
Surface Element
8"- 6 Turn
1600W@208V 2125W@240V
Replacement for GE



Part No. **S356**
Surface Element
6"- 5 Turn
1000W@208V 1325W@240V
Replacement for GE



Part No. **S359**
Surface Element
6"- 5 Turn
1000W@208V 1325W@240V
Replacement for GE



Part No. **WB30K10002**
Surface Element
6"- 3 Turn
940W@208V 1250W@240V
Replacement for GE



Part No. **WB30K10003**
Surface Element
8"- 4 Turn
1580W@208V 2100W@240V
Replacement for GE



Part No. **WB30T10074**
Surface Element
8"- 5 Turn
1950W@208V 2600W@240V
Replacement for GE



Part No. **WB30T10078**
Surface Element
6"- 4 Turn
1130W@208V 1500W@240V
Replacement for GE



Part No. **5304516159**
Surface Element (8" Safety)
2400W@240V
Replacement for Electrolux



Part No. **5304516160**
Surface Element (6" Safety)
1500W@240V
Replacement for Electrolux



Part No. **WB30X31057**
Surface Element (8" Safety)
2400W@240V
Replacement for GE



Part No. **WB30X31058**
Surface Element (6" Safety)
 1250W@240V
 Replacement for GE



Part No. **8273992**
Surface Element (Radiant Heat)
 10", 2500W@240V
 Replacement for Whirlpool



Part No. **316282000**
Surface Element (Radiant Heat)
 9-7/8", 3000W@240V
 Replacement for Electrolux




Part No. **318601604**
Surface Element (Radiant Heat)
 Replacement for Electrolux



Part No. **DG47-00064A**
Surface Element (Radiant Heat)
 11-3/8", 3000W@240V
 Replacement for Samsung



Part No. **DG47-00065A**
Surface Element (Radiant Heat)
 11-7/8", 3000W@240V
 Replacement for Samsung



Part No. **DG47-00066A**
Surface Element (Radiant Heat)
 4400/3600/1800W@240V
 Replacement for Samsung



Part No. **DG47-00067A**
Surface Element (Radiant Heat)
 9-7/8", 3300/1400W@240V
 Replacement for Samsung



Part No. **RS65D12**
Surface Element (Radiant Heat)
 6-1/2", 1200W@240V
 Replacement for Electrolux, Whirlpool



Part No. **RS85D20**
Surface Element (Radiant Heat)
 8-1/2", 2000W@240V
 Replacement for GE, Whirlpool



Part No. **RS975D25**
Surface Element (Radiant Heat)
 10", 2500W@240V
 Replacement for Electrolux, Whirlpool



Part No. **W10275048**
Surface Element (Radiant Heat)
 10", 3000W@240V
 Replacement for Whirlpool



Part No. **WB30T10044**
Surface Element (Radiant Heat)
10", 2500W@240V
Replacement for GE



Part No. **WB30T10045**
Surface Element (Radiant Heat)
8-1/2", 2000W@240V
Replacement for GE



Part No. **WB30T10047**
Surface Element (Radiant Heat)
7", 1500W@240V
Replacement for GE



Part No. **WB30T10126**
Surface Element (Radiant Heat)
11-3/4", 3000/1950/1050W@240V
Replacement for GE



Part No. **WB30T10129**
Surface Element (Radiant Heat)
7-1/8", 1500W@240V
Replacement for GE




Part No. **WB30T10130**
Surface Element (Radiant Heat)
11-3/4", 3000/1950W@240V
Replacement for GE



Part No. **WB30T10132**
Surface Element (Radiant Heat)
8-1/2", 2000W@240V
Replacement for GE



Part No. **WB30T10133**
Surface Element (Radiant Heat)
9-3/4", 3100/1300W@240V
Replacement for GE



Part No. **WB30T10135**
Surface Element (Radiant Heat)
10", 1900/800W@240V
Replacement for GE



Part No. **WB30T10136**
Surface Element (Radiant Heat)
9-1/8", 2500W@240V
Replacement for GE



Part No. **WB30T10145**
Surface Element (Radiant Heat)
6-1/2", 1200W@240V
Replacement for GE




Part No. **WB30T10155**
Surface Element (Radiant Heat)
12", 3600/2400/1400W@240V
Replacement for GE



Part No. **WB30X24111**
Surface Element (Radiant Heat)
 9-3/4", 3100/1300W@240V
 Replacement for GE



Part No. **9755542**
Temperature Probe
 Replacement for Whirlpool



Part No. **12001676**
Terminal Block
 Replacement for Whirlpool



Part No. **330031**
Terminal Block
 Replacement for Whirlpool



Part No. **R117**
Terminal Block
 Universal Replacement




Part No. **WB2X8228**
Terminal Block
 Replacement for GE



Part No. **WB17T10006**
Terminal Block
 Replacement for GE



Part No. **WB17X5051**
Terminal Block
 Replacement for GE



Part No. **WB17X5113**
Terminal Block
 Replacement for GE



Part No. **9759242**
Thermal Fuse
 Cutout @ 130°
 Replacement for Whirlpool



Part No. **9759243**
Thermal Fuse
 Cutout @ 120°
 Replacement for Whirlpool




Part No. **WB19K10025**
Thermocouple
 Replacement for GE



Part No. **1842A57**
Thermostat (Electric)
 250V, 22 amp, 7 terminals
 Includes OEM knob
 Replacement for Brown



Part No. **2167**
Thermostat (Electric)
 240V, 17 amp, 4 terminals
 Single pole with variable broil, 36" capillary
 Replacement for Peerless



Part No. **2168**
Thermostat (Electric)
 240V, 17 amp, 6 terminals
 Single pole with variable broil, 50" capillary
 Replacement for Peerless



Part No. **316032411**
Thermostat (Gas/Electric)
 125V, 5 amp, 2 terminals
 Replacement for Electrolux



Part No. **316215900**
Thermostat (Electric)
 250V, 60 Hz, 25 amp, 7 terminals
 Replacement for Electrolux



Part No. **316215901**
Thermostat (Electric)
 250V, 25 amp, 7 terminals
 Replacement for Electrolux



Part No. **3196803**
Thermostat (Electric)
 240V, 25 amp, 3 terminals, Double pole
 Replacement for Whirlpool



Part No. **6700S0011**
Thermostat (Universal Electric)
 240V, 17 amp, 6 terminals
 Replaces most single or double pole thermostats



Part No. **74002390**
Thermostat (Gas/Electric)
 125V, 5 amp, 2 terminals
 Replacement for Whirlpool



Part No. **74005019**
Thermostat (Electric)
 240V, 27 amp, 8 terminals, Double pole
 Replacement for Whirlpool



Part No. **98003984**
Thermostat (Gas/Electric)
 3/4" shaft, 2 terminals, single pole
 120V, 5 amp, 36" capillary
 Replacement for Whirlpool



Part No. **W10159016**
Thermostat (Gas/Electric)
 3/4" shaft, 2 terminals, single pole
 120V, 5 amp, 36" capillary
 Replacement for Whirlpool



Part No. **WB20K8**
Thermostat (Gas/Electric)
 3/4" shaft, 2 terminals, single pole
 120V, 5 amp, 36" capillary
 Replacement for GE



Part No. **WB20K5027**
Thermostat (Electric)
 250V, 25 amp, 5 terminals
 Replacement for GE



Part No. **WB20K10010**
Thermostat (Electric)
 240V, 20 amp, 6 terminals
 Replacement for GE



Part No. **WB20K10013**
Thermostat (Gas)
 3/4" shaft, 3 outlets
 Standing pilot, Bolt thru mount
 Replacement for GE




Part No. **WB20K10023**
Thermostat (Gas/Electric)
 120V, 20 amp, 2 terminals
 Replacement for GE



Part No. **WB20K10026**
Thermostat (Electric)
 240V, 20 amp, 6 terminals
 Replacement for GE



Part No. **WB20X5071**
Thermostat (Electric)
 240V, 30 amp, 6 terminals
 Replacement for GE



Part No. **WB21X5287**
Thermostat (Electric)
 250V, 25 amp, 5 terminals
 Replacement for GE

DISHWASHER



Part No. **8269145**

Bracket

Replacement for Whirlpool



Part No. **8268383**

Chopper Assembly

Replacement for Whirlpool



Part No. **490467**

Detergent Dispenser

Replacement for Bosch



Part No. **DM06N**

Dishwasher Magic

(Sold in 6PK case ONLY)

Removes mineral build-up, cleans & disinfects
Safe for dishwashers, plumbing & septic systems



Part No. **DM24F**

Dishwasher Magic

24 piece floor display



Part No. **W10508950**

Dishrack Stop (2pk)

Replacement for Whirlpool



Part No. **W10537869**

Diverter Motor

Replacement for Whirlpool



Part No. **00754866**

Door Spring Kit

Replacement for Bosch



Part No. **00754873**

Door Spring Kit

Replacement for Bosch



Part No. **DWDH78**

Drain Hose

1/2" ID x 78" length

Can be cut and used as extension hose

Universal Replacement



Part No. **154825001**

Element

15-3/4" x 15-3/4" with male spade terminals

Replacement for Electrolux



Part No. **00494772**

Gasket

73" length

Replacement for Bosch



Part No. **3920DD3005A**
Gasket
74-3/4" length
Replacement for LG



Part No. **902894**
Gasket
76" length
Replacement for Whirlpool



Part No. **154827601**
Gasket
86-1/2" length
Replacement for Electrolux



Part No. **DD62-00043A**
Gasket
73" length
Replacement for Samsung



Part No. **W10300924V**
Gasket
71-1/2" length
Replacement for Whirlpool



Part No. **W10509257**
Gasket
65-1/4" length
Replacement for Whirlpool



Part No. **W10524469**
Gasket
72-7/8" length
Replacement for Whirlpool



Part No. **WD08X10057**
Gasket
89-1/2" length
Replacement for GE



Part No. **WD8X227**
Gasket (Right Corner)
Replacement for GE



Part No. **WD8X228**
Gasket (Left Corner)
Replacement for GE



Part No. **WD8X229**
Gasket
89" length
Replacement for GE



Part No. **00167085**
Impeller & Seal Kit
Replacement for Bosch

DISHWASHER



Part No. **34FHT**
Inlet
 90 degree
 Replacement for Whirlpool



Part No. **WD21X10261**
Interlock Switch
 Replacement for GE



Part No. **8194001**
Link Kit
 2 Pack
 Replacement for Whirlpool



Part No. **00436440**
Pump (Drain)
 Replacement for Bosch



Part No. **00611332**
Pump (Drain)
 Replacement for Bosch



Part No. **00620774**
Pump (Drain)
 Replacement for Bosch



Part No. **642239**
Pump (Drain)
 Replacement for Bosch



Part No. **661658**
Pump (Drain)
 Replacement for Whirlpool



Part No. **154580301**
Pump (Drain)
 Replacement for Electrolux



Part No. **A00126401**
Pump
 Replacement for Electrolux



Part No. **A00126501**
Pump (Drain)
 Replacement for Electrolux



Part No. **DD31-00005A**
Pump (Drain)
 Replacement for Samsung



Part No. **DD31-00016A**
Pump (Drain)
Replacement for Samsung



Part No. **W10348269**
Pump
Replacement for Whirlpool




Part No. **W10510667**
Pump (Motor)
Replacement for Whirlpool



Part No. **W10876537**
Pump
Replacement for Whirlpool



Part No. **W10311986**
Rack (Lower)
Includes four rollers
Replacement for Whirlpool



Part No. **W10712394**
Rack Adjuster Kit
Replacement for Whirlpool



Part No. **00611666**
Roller
Replacement for Bosch



Part No. **165314**
Roller
Replacement for Bosch



Part No. **611475**
Roller
Replacement for Bosch



Part No. **WD12X271**
Roller
Replacement for GE



Part No. **12004485**
Roller Kit (8pk)
Replacement for Bosch



Part No. **8268743**
Roller Assembly
Replacement for Whirlpool

DISHWASHER



Part No. **8561996**
Roller Assembly (Adjustable)
Replacement for Whirlpool



Part No. **W10195416**
Roller Assembly
Replacement for Whirlpool



Part No. **809006501**
Seal (Lower)
22-1/2" length
Replacement for Electrolux



Part No. **154701001**
Splash Shield Kit
Replacement for Electrolux



Part No. **154568001**
Spray Arm (Lower)
Replacement for Electrolux




Part No. **5304506516**
Spray Arm (Upper)
Replacement for Electrolux



Part No. **5304518927**
Spray Arm
Replacement for Electrolux




Part No. **154430501**
Spring
Replacement for Electrolux



Part No. **DD94-01006A**
Temperature Sensor
Replacement for Samsung



Part No. **675813**
Thermal Fuse
Replacement for Whirlpool



Part No. **8193762**
Thermal Fuse
Replacement for Whirlpool



Part No. **W10258275**
Thermal Fuse
Replacement for Whirlpool



Part No. **W10402110**
Thermal Fuse
Replacement for Whirlpool



Part No. **DD32-00005A**
Thermister
Replacement for Samsung



Part No. **661566**
Thermostat
Replacement for Whirlpool



Part No. **00628334**
Water Valve
Replacement for Bosch



Part No. **425458**
Water Valve
Replacement for Bosch



Part No. **607335**
Water Valve
Replacement for Bosch



Part No. **622058**
Water Valve
Replacement for Bosch



Part No. **8531669**
Water Valve
Replacement for Whirlpool



Part No. **154637401**
Water Valve
Replacement for Electrolux



Part No. **807047901**
Water Valve
Replacement for Electrolux



Part No. **DD62-00067A**
Water Valve
Replacement for Samsung



Part No. **DD62-00084A**
Water Valve
Replacement for Samsung

DISHWASHER



Part No. **W10158389**
Water Valve
Replacement for Whirlpool



Part No. **W10219643**
Water Valve
Replacement for Whirlpool




Part No. **W10327249**
Water Valve
Replacement for Whirlpool



Part No. **W11175771**
Water Valve
Replacement for Whirlpool



Part No. **WD15X10003**
Water Valve
Replacement for GE



Part No. **WD15X10011**
Water Valve
Replacement for GE



Part No. **33002032**

Baffle

Replacement for Whirlpool



Part No. **4400EL2001A**

Belt

Replacement for LG



Part No. **6602-001655**

Belt

Replacement for Samsung



Part No. **312959**

Belt

Replacement for Whirlpool



Part No. **341241**

Belt

Replacement for Whirlpool



Part No. **3394652**

Belt

Replacement for Whirlpool



Part No. **8544742**

Belt

Replacement for Whirlpool



Part No. **8547157**

Belt

Replacement for Whirlpool



Part No. **40111201**

Belt

Replacement for Whirlpool



Part No. **134719300**

Belt

Replacement for Electrolux



Part No. **137051400**

Belt

Replacement for Electrolux



Part No. **137292700**

Belt

Replacement for Electrolux



Part No. **W10136934**
Belt
Replacement for Whirlpool



Part No. **WE12X82**
Belt
Replacement for GE



Part No. **WE12X10015**
Belt
Replacement for GE



Part No. **303836**
Blower Wheel
Replacement for Whirlpool



Part No. **694089**
Blower Wheel
Replacement for Whirlpool



Part No. **B68C**
Brush (Vent Duct)
10 foot length, 4" diameter bristles



Part No. **W10328463**
Coil
Replacement for Whirlpool



Part No. **DE382**
Coil Kit (Primary & Secondary)
Universal Replacement



Part No. **W10861225**
Door Handle
Replacement for Whirlpool



Part No. **279570**
Door Latch
Replacement for Whirlpool



Part No. **279570M**
Door Latch
Replacement for Whirlpool



Part No. **6601EL3001A**
Door Switch
Replacement for LG



Part No. **3406105**
Door Switch (Lid)
Replacement for Whirlpool



Part No. **3406107**
Door Switch (Start)
Replacement for Whirlpool



Part No. **3406108**
Door Switch
Replacement for Whirlpool



Part No. **DC64-00828A**
Door Switch
Replacement for Samsung



Part No. **1153KIT**
Drum Bearing (Hub & Belt Kit)
Replacement for Electrolux



Part No. **5303281153**
Drum Bearing
Replacement for Electrolux



Part No. **WE3M26**
Drum Bearing (Front)
Replacement for GE



Part No. **WE25X205**
Drum Bearing Kit
Replacement for GE



Part No. **WE49X20697**
Drum Bearing Kit
Replacement for GE



Part No. **37001298**
Drum Glide
Replacement for Whirlpool



Part No. **5303937139**
Drum Glide
Replacement for Electrolux



Part No. **279408**
Drum Seal
Replacement for Whirlpool



Part No. **279735**
Drum Seal
Replacement for Whirlpool



Part No. **5303937182**
Drum Seal
Replacement for Electrolux



Part No. **WE1M333**
Drum Slide
Replacement for GE



Part No. **WE1M1067**
Drum Slide
Replacement for GE



Part No. **5301EL1001G**
Element
Replacement for LG



Part No. **61927**
Element
Replacement for Whirlpool




Part No. **279838**
Element
Replacement for Whirlpool




Part No. **303404**
Element
Replacement for Whirlpool



Part No. **3387747**
Element
Replacement for Whirlpool



Part No. **4391960**
Element
Replacement for Whirlpool



Part No. **8544771**
Element
Replacement for Whirlpool



Part No. **134792700**
Element
Replacement for Electrolux




Part No. **137114000**
Element
 Replacement for Electrolux



Part No. **5300622032**
Element
 Replacement for Electrolux



Part No. **5300622034**
Element
 Replacement for Electrolux



Part No. **DC47-00019A**
Element
 Replacement for Samsung



Part No. **DC97-14486A**
Element
 Replacement for Samsung



Part No. **LA1044**
Element
 Replacement for Whirlpool




Part No. **33001807**
Felt
 78-1/2" length
 Replacement for Whirlpool



Part No. **5303283286**
Felt
 48-1/2" length
 Replacement for Electrolux



Part No. **WE09X20441**
Felt
 46" length
 Replacement for GE



Part No. **338906**
Flame Sensor
 Replacement for Whirlpool



Part No. **110222**
Foil Duct (25 foot)
 Exceeds UL®181, Class 1 air connector label
 Manufacturer assumes no responsibility for failure due to improper installation.
 Please check your installation instructions and your local building codes for proper use.



Part No. **4560EL3001A**
Idler Pulley
 Replacement for LG



Part No. **4561EL3002A**
Idler Pulley
Replacement for LG



Part No. **279640**
Idler Pulley
Replacement for Whirlpool



Part No. **691366**
Idler Pulley
Replacement for Whirlpool



Part No. **8547174**
Idler Pulley
Replacement for Whirlpool



Part No. **37001287**
Idler Pulley
Replacement for Whirlpool



Part No. **6-3700340**
Idler Pulley
Replacement for Whirlpool



Part No. **DC93-00634A**
Idler Pulley
Replacement for Samsung




Part No. **W10547292**
Idler Pulley
Replacement for Whirlpool



Part No. **W10837240**
Idler Pulley
Replacement for Whirlpool



Part No. **5318EL3001A**
Igniter
Replacement for LG



Part No. **279311**
Igniter
Replacement for Whirlpool



Part No. **31001556**
Igniter
Replacement for Whirlpool



Part No. **DC47-00022A**
Igniter
Replacement for Samsung



Part No. **UDI**
Igniter
Universal Replacement



Part No. **WE4X444**
Igniter
Replacement for GE



Part No. **WE4X739**
Igniter
Replacement for GE



Part No. **WE4X750**
Igniter
Replacement for GE



Part No. **137544800**
Inlet Mist Valve
Replacement for Electrolux



Part No. **134844470**
Knob
1-1/2" dia., 1/4" ext. shaft, 6 o'clock flat
Replacement for Electrolux



Part No. **134886700**
Knob
3" dia., flush shaft, 6 o'clock flat
Replacement for Electrolux



Part No. **W11176265**
Knob
1-7/8" dia., 3/8" ext. shaft, 12 o'clock flat
Replacement for Whirlpool



Part No. **WE01X10160**
Knob
2" dia., 3/4" ext. shaft, 6 o'clock flat
Replacement for GE



Part No. **WE01X20374**
Knob
2-3/4" dia., 1/8" ext. shaft, 12 o'clock flat
Replacement for GE



Part No. **WE1M652**
Knob
1-3/4" dia., 1/8" ext. shaft, 12 o'clock flat
Replacement for GE



Part No. **WE1M654**
Knob
2-3/4" dia., 1/8" ext. shaft, 12 o'clock flat
Replacement for GE



Part No. **WE1X1263**
Knob
2-7/8" dia., 1/8" ext. shaft, 12 o'clock flat
Replacement for GE



Part No. **DVC202PK**
Linteater (Vent Cleaning)
Removes lint build up
Helps prevent dryer fires
Easy to use with your cordless drill
Sold in 6PK ONLY



Part No. **EXT12FT**
Linteater Extension Kit
4 - 36" flexible rods
Screw together to reach into vents up to
12 feet from dryer



Part No. **00652184**
Lint Filter
Replacement for Bosch



Part No. **5231EL1003B**
Lint Filter
Replacement for LG



Part No. **8531964**
Lint Filter
Replacement for Whirlpool



Part No. **W10120998**
Lint Filter
Replacement for Whirlpool



Part No. **WE18X25100**
Lint Filter
Replacement for GE



Part No. **53-0918**
Lint Screen
Replacement for Whirlpool



Part No. **339392**
Lint Screen
Replacement for Whirlpool



Part No. **349639**
Lint Screen
Replacement for Whirlpool



Part No. **8557884**
Lint Screen
Replacement for Whirlpool



Part No. **33001003**
Lint Screen
Replacement for Whirlpool



Part No. **33001808**
Lint Screen
Replacement for Whirlpool



Part No. **33002970**
Lint Screen
Replacement for Whirlpool



Part No. **W10717210**
Lint Screen
Replacement for Whirlpool



Part No. **WE18X26**
Lint Screen
Replacement for Whirlpool



Part No. **DC31-00055G**
Motor
2-1/4" shaft
Replacement for Samsung



Part No. **279393**
Nut & Bolt Kit
Replacement for Whirlpool



Part No. **4392065**
Rebuild Kit
Replacement for Whirlpool



Part No. **3700KIT2**
Repair Kit
Replacement for Whirlpool



Part No. **4392067**
Repair Kit
Replacement for Whirlpool



Part No. **4581KIT4**
Repair Kit
Replacement for LG



Part No. **DC97KIT4**
Repair Kit
Replacement for Samsung



Part No. **4581EL2002A**
Roller
Replacement for LG



Part No. **303373K**
Roller
Replacement for Whirlpool



Part No. **349241**
Roller
Replacement for Whirlpool



Part No. **349241T**
Roller
Replacement for Whirlpool



Part No. **12001541**
Roller
Replacement for Whirlpool



Part No. **37001042**
Roller
Replacement for Whirlpool



Part No. **134715900**
Roller
Replacement for Electrolux



Part No. **DC97-16782A**
Roller
Replacement for Samsung



Part No. **W10314173**
Roller
Replacement for Whirlpool



Part No. **LA1008**
Roller Kit
Replacement for Whirlpool



Part No. **SKK-7A**
Stacking Kit
Replacement for Samsung



Part No. **197**
Thermal Cut Off Kit
Replacement for Whirlpool



Part No. **279816**
Thermal Cut Off Kit
Replacement for Whirlpool




Part No. **279769**
Thermal Fuse
Replacement for Whirlpool



Part No. **279973**
Thermal Fuse
Replacement for Whirlpool



Part No. **3390719**
Thermal Fuse
Replacement for Whirlpool



Part No. **3392519**
Thermal Fuse
Replacement for Whirlpool



Part No. **3399849**
Thermal Fuse
Replacement for Whirlpool



Part No. **40113801**
Thermal Fuse
Replacement for Whirlpool



Part No. **134120900**
Thermal Fuse
Replacement for Electrolux



Part No. **137032600**
Thermal Fuse
Replacement for Electrolux



Part No. **137539200**
Thermal Fuse
Replacement for Electrolux



Part No. **DC47-00016A**
Thermal Fuse
Replacement for Samsung



Part No. **DC96-00887A**
Thermal Fuse
Replacement for Samsung



Part No. **LA1053**
Thermal Fuse Kit
Replacement for Whirlpool



Part No. **8577274**
Thermistor
Replacement for Whirlpool



Part No. **DC32-00007A**
Thermistor
Replacement for Samsung



Part No. **3204267**
Thermostat
Replacement for Electrolux



Part No. **3387134**
Thermostat
Replacement for Whirlpool



Part No. **3977767**
Thermostat
Replacement for Whirlpool



Part No. **6931EL3001E**
Thermostat
Replacement for LG



Part No. **6931EL3003C**
Thermostat
Replacement for LG



Part No. **6931EL3003D**
Thermostat
Replacement for LG



Part No. **DC47-00017A**
Thermostat
Replacement for Samsung



Part No. **DC47-00018A**
Thermostat
Replacement for Samsung



Part No. **L290**
Thermostat
Universal Replacement



Part No. **W10185970**
Timer
Replacement for Whirlpool



Part No. **W10185976**
Timer
Replacement for Whirlpool



Part No. **W10185981**
Timer
Replacement for Whirlpool



Part No. **W10186032**
Timer
Replacement for Whirlpool



Part No. **W10436303**
Timer
Replacement for Whirlpool



Part No. **W10745655**
Timer
Replacement for Whirlpool

Part No. **WCOIL**
A/C Coil Cleaner
 20 oz.
 For A/C and heat pump coils



Part No. **LA11AA005**
Blower Wheel
 4" diameter
 Replacement for Carrier



Part No. **0130F00010KIT**
Flame Sensor (6pk)
 Replacement for Goodman



Part No. **LH680014**
Flame Sensor
 Replacement for Carrier



Part No. **02532625000**
Furnace Igniter
 Replacement for York




Part No. **1090**
Furnace Igniter
 Universal Replacement



Part No. **1408**
Furnace Igniter
 Universal Replacement



Part No. **1409**
Furnace Igniter
 Universal Replacement



Part No. **1474052P**
Furnace Igniter
 Replacement for Coleman



Part No. **20165703S**
Furnace Igniter
 Replacement for Goodman




Part No. **903758**
Furnace Igniter
 Replacement for Whirlpool



Part No. **622266992**
Furnace Igniter
 Replacement for Rheem





Part No. **B1401018S**
Furnace Igniter
 Replacement for Goodman



Part No. **IG101**
Furnace Igniter
 Universal Replacement




Part No. **H-301**
Ice Machine Cleaner
 1 gallon
 Nickel safe - meets Manitowac spec. GES-6



Part No. **H-316**
Ice Machine Cleaner
 1 pint
 Nickel safe - meets Manitowac spec. GES-6



Part No. **1003**
Ignition Module
 24VAC, 50/60 Hz
 Prepurge: 1 sec.
 90 sec. trial, 5 min. retry
 Universal Replacement



Part No. **60J00**
Ignition Module
 24VAC, 50/60 Hz
 Replacement for Lennox



Part No. **B1859005**
Motor (Blower)
 115V, 60 Hz, 3000 RPM
 Replacement for Janitrol



Part No. **1013833**
Motor (Inducer)
 115V, 60 Hz, 1.47 amps, 1/35 HP
 Replacement for Heil




Part No. **318984-753**
Motor (Inducer)
 115V, 1.8 amps, 3300 RPM
 Replacement for Carrier



Part No. **LH680005**
Pilot Assembly
 Replacement for Carrier



Part No. **SHUBEE**
Shoe Covers (Dark Blue)
 Sold in 50pk ONLY



For professional use only:
 Always wear safety glasses
 and protective gloves. Use in
 compliance with the
 Montreal Protocol and
 Regional or Federal laws for
 the handling of refrigerant.

Part No. **944KIT**
Super Seal (HVACR)
 Repairs leaks in refrigerant units utilizing more
 than 4 lbs. of refrigerant
 1-1/2 ton up to 5 ton (min. of 30 oz. of oil req.)
 Compatible w/all refrigerants & oils includ. 410a



For professional use only:
Always wear safety glasses
and protective gloves. Use in
compliance with the
Montreal Protocol and
Regional or Federal laws for
the handling of refrigerant.

Part No. **947KIT**

Super Seal (ACR) 1 unit

Repairs leaks in refrigerant units utilizing less than 4 lbs. of refrigerant
230 BTUH up to 18000 BTUH (1-1/2 ton) (min. of 10 oz. of oil
required)

Compatible with all refrigerants & oils including 410a



For professional use only:
Always wear safety glasses
and protective gloves. Use in
compliance with the
Montreal Protocol and
Regional or Federal laws for
the handling of refrigerant.

Part No. **971KIT**

Super Seal (Total 1)

Used on small systems

Contains Super Seal Classic, Dry R and an Ultra Violet (UV) tracer dye
Compatible with all refrigerants & oils, for preventative maintenance



Part No. **ZC-02**

Zip-Clean Coil Cleaner

18 oz.

Cleans evaporator coils quickly & easily
Prevents future dirt build up



Part No. **ZS75**

Zoom Spout Oiler

4 oz.

All purpose turbine oil
Spout applicator telescopes to 14"



Part No. **26QBP0213**
Bulb
 120V, 20 watts, 1-5/8" high



Part No. **26QBP0264**
Bulb
 130V, 40 watts, 2-5/8" high



Part No. **26QBP0930**
Bulb
 120V, 20 watts, 2-1/4" high



Part No. **26QBP3236**
Bulb
 130V, 40 watts, 2-7/8" high



Part No. **26QBP4076**
Bulb
 120V, 30 watts, 2-3/16" high



Part No. **26QBP4093**
Bulb
 130V, 40 watts, 2-1/4" high



Part No. **13QBP21090**
Capacitor (High Voltage)
 2100V, 0.90µf, 1/4" terminal size



Part No. **13QBP21095**
Capacitor (High Voltage)
 2100V, 0.95µf 1/4" terminal size



Part No. **13QBP21100**
Capacitor (High Voltage)
 2100V, 1.00µf 1/4" terminal size



Part No. **13QBP21105**
Capacitor (High Voltage)
 2100V, 1.05µf 1/4" terminal size



Part No. **14QBP20CFB**
Ceramic Fuse (Fast blow)
 250V, 20 amp, 1-1/4" length

Part No. **14QBP20CSB**
Ceramic Fuse (Slow blow)
 250V, 20 amp, 1-1/4" length



Part No. **11QBP0236**
Diode (High Voltage)
 3-1/2" length, 12 kV, 350 mA



Part No. **11QBPUNIV**
Diode (High Voltage)
 3-5/8" length, 12 kV, 350 mA



Part No. **25QBP3779**
Door Handle
 11-5/8" length x 1-1/8" width
 Replacement for GE #WB15X10020



Part No. **25QBP3780**
Door Handle
 11-5/8" length x 1-1/8" width
 Replacement for GE #WB15X335



Part No. **25QBP3784**
Door Handle
 11-3/16" length x 1-1/8" width
 Replacement for GE #WB15X10022



Part No. **25QBP3785**
Door Handle
 11-3/16" length x 1-1/8" width
 Replacement for GE #WB15X10023




Part No. **5304477398**
Door Handle
 10-7/8" length x 1-1/4" width
 Replacement for Electrolux




Part No. **4750**
Magic Lights Microwave Tester
 Checks microwave power settings
 Finds hot and cold spots
 No batteries needed




Part No. **10QBP0228**
Magnetron
 4.1 kV, 700-800 watts, Compact type, K Configuration, 30mm antenna




Part No. **10QBP0229**
Magnetron
 4.1 kV, 700-850 watts, Standard type, J Configuration, 30mm antenna



Part No. **10QBP0230**
Magnetron
 4.1 kV, 700-850 watts, Standard type, J Configuration, 30mm antenna






Part No. **10QBP0231**

Magnetron


4.1 kV, 700-850 watts, Standard type, H Configuration, 30mm antenna



Part No. **10QBP0232**

Magnetron


4.1 kV, 700-850 watts, Standard type, K Configuration, 30mm antenna



Part No. **10QBP0234**

Magnetron


4.1 kV, 700-800 watts, Compact type, J Configuration, 30mm antenna



Part No. **10QBP0235**

Magnetron


4.1 kV, 700-850 watts, Standard type, E Configuration, 30mm antenna



Part No. **10QBP1000**

Magnetron


4.35 kV, 900-1000 watts, Standard type, J Configuration, 30mm antenna



Part No. **10QBP1003**

Magnetron


4.35 kV, 900-1000 watts, Standard type, H Configuration, 30mm antenna



Part No. **10QBP1004**

Magnetron

4.35 kV, 900-1000 watts, Standard type, K Configuration, 30mm antenna



Part No. **10QBP1006**

Magnetron

4.35 kV, 1000 watts, Standard type, J Configuration, 30mm antenna

MICROWAVE

MICROWAVE



Part No. **98QBP0300**
Paint (Spray)
 6 oz., Pearl/Off White
 Formulated specifically for use on microwaves



Part No. **98QBP0302**
Paint (Spray)
 6 oz., Snow/Bright White
 Formulated specifically for use on microwaves



Part No. **98QBP0303**
Paint (Touch Up)
 1/2 oz. with brush, Snow/Bright White
 Formulated specifically for use on microwaves



Part No. **28QBP0491**
Switch (Button Type)
 Latch Application
 SPST NO, 22 amps, 125/250V
 .020 x .187 terminal



Part No. **28QBP0495**
Switch (Button Type)
 Universal Application
 SPDT NO/NC, 16 amps, 125/250V
 .020 x .187 terminal



Part No. **28QBP0496**
Switch (Button Type)
 Universal Application
 SPDT NO/NC, 16 amps, 125/250V
 .320 x .250 terminal



Part No. **28QBP0497**
Switch (Button Type)
 Latch Application
 SPST NO, 16 amps, 125/250V
 .020 x .187 terminal



Part No. **28QBP0499**
Switch (Button Type)
 Latch Application
 SPST NO, 16 amps, 125/250V
 .020 x .187 terminal



Part No. **30QBP0663**
Turntable Tray
 12-3/4" diameter



Part No. **30QBP1848**
Turntable Tray
 12-1/2" diameter
 Replaces GE #WB39X10003



Part No. **30QBP4185**
Turntable Tray
 11-7/8" diameter
 Replaces Whirlpool #4393799



Part No. **40QBP1012**
Waveguide Cover
 15-3/8" x 9-1/2"
 Cut to fit, Mica construction
 Universal Replacement



Part No. **EAFCBF**
Air Filter
Replacement for Electrolux



Part No. **WR02X12208**
Appliance Bulb
12V, 6 watt, 1-7/8" high



Part No. **W10321304**
Bin (Clear)
Replacement for Whirlpool



Part No. **5304464438**
Capacitor
Replacement for Electrolux



Part No. **2198202**
Cold Control
Replacement for Whirlpool



Part No. **2200859**
Cold Control
Replacement for Whirlpool



Part No. **5304404821**
Cold Control
Replacement for Electrolux



Part No. **5304421256**
Cold Control
Replacement for Electrolux



Part No. **5304513033**
Cold Control
Replacement for Electrolux



Part No. **W11088945**
Cold Control
Replacement for Whirlpool



Part No. **WR09X10042**
Cold Control
Replacement for GE




Part No. **WR9X355**
Cold Control
Replacement for GE

REFRIGERATION



Part No. **WR9X491**
Cold Control
 Replacement for GE



Part No. **W10352689**
Control Board
 Replacement for Whirlpool



Part No. **241993001**
Crisper Support
 Replacement for Electrolux



Part No. **2263749**
Defrost Heater
 Calrod, 475 watts @ 120V
 Replacement for Whirlpool



Part No. **2323198**
Defrost Heater
 Calrod, 614 watts @ 120V
 Replacement for Whirlpool



Part No. **61001846**
Defrost Heater
 Quartz Tube, 575 watts @ 115V
 10-3/8" tube length
 Replacement for Whirlpool



Part No. **67002493**
Defrost Heater
 Calrod, 600 watts @ 115V
 Replacement for Whirlpool




Part No. **242044020**
Defrost Heater
 Calrod, 375 watts @ 115V
 Replacement for Electrolux



Part No. **242044113**
Defrost Heater
 Calrod, 450 watts @ 115V
 Replacement for Electrolux




Part No. **DA47-00244B**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung



Part No. **DA47-00244D**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung



Part No. **DA47-00322J**
Defrost Heater
 Calrod, 140 watts @ 120V
 Replacement for Samsung



Part No. **DA47-00424A**
Defrost Heater
 Calrod, 240 watts @ 115V
 Replacement for Samsung




Part No. **DA47-00424B**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung



Part No. **DA47-00424L**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung



Part No. **WR49X392**
Defrost Heater
 Quartz Tube, 775 watts @ 115V
 12-1/2" tube length
 Replacement for GE



Part No. **WR51X442**
Defrost Heater
 Quartz Tube, 600 watts @ 115V
 9-1/2" tube length
 Replacement for GE



Part No. **WR51X443**
Defrost Heater
 Quartz Tube, 770 watts @ 115V
 12-13/16" tube length
 Replacement for GE



Part No. **WR51X10031**
Defrost Heater
 Quartz Tube, 575 watts @ 115V
 9-1/2" tube length
 Replacement for GE



Part No. **WR51X10038**
Defrost Heater
 Quartz Tube, 375 watts @ 115V
 21" tube length
 Replacement for GE



Part No. **WR51X10053**
Defrost Heater
 Quartz Tube, 575 watts @ 115V
 9-1/2" tube length
 Replacement for GE



Part No. **WR51X10055**
Defrost Heater
 Quartz Tube, 725 watts @ 115V
 12" tube length
 Replacement for GE



Part No. **2183400**
Defrost Timer
 8 hr. 25 min.
 Replacement for Whirlpool



Part No. **215846602**
Defrost Timer
 8 hr. 30 min.
 Replacement for Electrolux

REFRIGERATION



Part No. **241705102**
Defrost Timer
 12 hr. 25 min.
 Replacement for Electrolux



Part No. **GP1**
Defrost Timer
 6 hr. 21 min.
 Universal Replacement



Part No. **GP11**
Defrost Timer
 8 hr. 21 min.
 Universal Replacement



Part No. **W10822278**
Defrost Timer
 8 hr. 21 min.
 Replacement for Whirlpool



Part No. **WR09X10049**
Defrost Timer
 15 hr. 34 min.
 Replacement for GE



Part No. **WR9X480**
Defrost Timer
 6 hr. 30 min.
 Replacement for GE



Part No. **WR9X483**
Defrost Timer
 10 hr. 30 min.
 Replacement for GE



Part No. **WR9X489**
Defrost Timer
 16 hr. 35 min.
 Replacement for GE



Part No. **WR9X502**
Defrost Timer
 8 hr. 30 min.
 Replacement for GE



Part No. **WR9X520**
Defrost Timer
 5 hr. 44 min.
 Replacement for GE



Part No. **4387490**
Defrost Thermostat
 L58-14F, 5/16" side push on clip
 24" leads with stripped wire ends
 Replacement for Whirlpool



Part No. **4387503**
Defrost Thermostat
 L62-14C, 3/8" side push on clip
 6" leads with stripped wire ends
 Replacement for Whirlpool



Part No. **67003426**
Defrost Thermostat
 L42-30C, 1/4" side push on clip
 7-1/2" & 24-1/2" leads w/stripped wire ends
 Replacement for Whirlpool



Part No. **218969902**
Defrost Thermostat
 L47-22F, 5/16" side push on clip
 Bullet connectors
 Replacement for Electrolux



Part No. **5303918202**
Defrost Thermostat
 L47-22C, 5/16" side push on clip
 4" & 6" leads with stripped wire ends
 Replacement for Electrolux



Part No. **5303918214**
Defrost Thermostat
 L47-22C, 1/4" side push on clip
 6" leads with stripped wire ends
 Replacement for Electrolux



Part No. **DA47-00243K**
Defrost Thermostat
 Replacement for Samsung



Part No. **DA47-00285P**
Defrost Thermostat
 Replacement for Samsung



Part No. **MLT45**
Defrost Thermostat
 Open@45 Close@25
 24" leads with stripped wire ends
 Universal Replacement



Part No. **MLT50**
Defrost Thermostat
 Open@50 Close@30
 24" leads with stripped wire ends
 Universal Replacement



Part No. **MLT55**
Defrost Thermostat
 Open@55 Close@35
 24" leads with stripped wire ends
 Universal Replacement



Part No. **MLT60**
Defrost Thermostat
 Open@60 Close@40
 24" leads with stripped wire ends
 Universal Replacement



Part No. **W10225581**
Defrost Thermostat
 L60-32C, 1/4" side push on clip
 11-3/4" leads with stripped wire ends
 Replacement for Whirlpool



Part No. **WR50X10025**
Defrost Thermostat
 L58-30F, 1/4" side push on clip
 4-1/2" & 15-1/2" leads with stripped wire ends
 Replacement for GE

REFRIGERATION



Part No. **WR50X10068**

Defrost Thermostat


L140-30C, 5/16" side push on clip
11" leads with stripped wire ends
Replacement for GE



Part No. **215366002**

Door Bar

30-3/4" x 1-11/16"
Replacement for Electrolux



Part No. **240331401**

Door Bar

20-1/4" x 1-3/4"
Replacement for Electrolux



Part No. **WR71X10077**

Door Bar

24-1/2" x 2"
Replacement for GE




Part No. **240338001**

Door Bin

24-3/8" x 6-1/4"
Replacement for Electrolux

Measurements are from end to end and not exact, to make sure you get the correct gasket, always go by model number.



* Due to shipping concerns, you must order a minimum of 2 rigid style gaskets (you may mix and match)



FRONT CORNER

BACK CORNER

Part No. **2159057***

Door Gasket (Fresh Food, White)

34-3/4" W x 47" L
Replacement for Whirlpool



FRONT CORNER

BACK CORNER

Part No. **2159061***

Door Gasket (Fresh Food, White)

34-1/2" W x 47-1/4" L
Replacement for Whirlpool




FRONT CORNER

BACK CORNER

Part No. **2159327**

Door Gasket (Freezer, White)

19-3/4" W x 28-1/8" L
Replacement for Whirlpool




FRONT CORNER

BACK CORNER

Part No. **2188436A**

Door Gasket (Freezer, White)

27-1/8" W x 60" L
Replacement for Whirlpool




FRONT CORNER

BACK CORNER

Part No. **2188448A**

Door Gasket (Fresh Food, Beige)

8" W x 32-1/4" L
Replacement for Whirlpool




FRONT CORNER

BACK CORNER

Part No. **2188462A**

Door Gasket (Freezer, White)


18-3/4" W x 27" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **2262080**
Door Gasket (Fresh Food, White)
8" W x 32-1/4" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **2319264T***
Door Gasket (Fresh Food, White)
12" W x 30-1/4" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **2319265T***
Door Gasket (Fresh Food, White)
12" W x 30-1/2" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **2319266T***
Door Gasket (Fresh Food, White)
12" W x 30-1/2" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **10359708Q**
Door Gasket (Fresh Food, White)
19" W x 31-1/2" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **12550109Q**
Door Gasket (Fresh Food, White)
28-1/4" W x 39-1/2" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **12550111Q**
Door Gasket (Fresh Food, White)
31-1/8" W x 41-1/4" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **12550115Q**
Door Gasket (Fresh Food, White)
8" W x 32-1/4" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **12550116Q**
Door Gasket (Freezer, White)
23-3/8" W x 30-7/8" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER


Part No. **61004003**
Door Gasket (Fresh Food, White)
12" W x 30-1/2" L
Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER

Part No. **61004008**
Door Gasket (Fresh Food, White)
12" W x 30-1/2" L
Replacement for Whirlpool




FRONT
CORNER

BACK
CORNER


Part No. **218730603**
Door Gasket (Fresh Food, White)
12-3/4" W x 30-1/2" L
Replacement for Electrolux

REFRIGERATION

Measurements are from end to end and not exact, to make sure you get the correct gasket, always go by model number.




* Due to shipping concerns, you must order a minimum of 2 rigid style gaskets (you may mix and match)



FRONT CORNER

BACK CORNER

Part No. **218730605**
Door Gasket (Fresh Food, White)
 19" W x 31-1/2" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER

Part No. **241872501***
Door Gasket (Freezer, White)
 18-3/4" W x 29-3/4" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER


Part No. **241872502***
Door Gasket (Fresh Food, White)
 27-1/2" W x 37" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER

Part No. **241872503***
Door Gasket (Freezer, White)
 19" W x 31-1/2" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER

Part No. **241872504***
Door Gasket (Fresh Food, White)
 18-3/4" W x 29-3/4" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER

Part No. **241872505***
Door Gasket (Freezer, White)
 20-1/2" W x 28-1/2" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER

Part No. **241872509***
Door Gasket (Freezer, Black)
 18" W x 28-1/2" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER


Part No. **241872510***
Door Gasket (Fresh Food, Black)
 27" W x 41" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER

Part No. **241872512***
Door Gasket (Fresh Food, Black)
 28-5/8" W x 41-3/4" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER

Part No. **241872513***
Door Gasket (Fresh Food, White)
 29-3/4" W x 42-3/4" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER

Part No. **241872514***
Door Gasket (Fresh Food, Black)
 29-1/2" W x 43" L
 Replacement for Electrolux



FRONT CORNER

BACK CORNER


Part No. **DA97-05253B**
Door Gasket (Fresh Food, Gray)
 17" W x 39-1/2" L
 Replacement for Samsung



FRONT CORNER

BACK CORNER


Part No. **DA97-05557Y**
Door Gasket (Freezer, Gray)
 23-1/2" W x 34-3/4" L
 Replacement for Samsung



FRONT CORNER

BACK CORNER


Part No. **WR24X445**
Door Gasket (Freezer, White)
 21-1/2" W x 29-1/2" L
 Replacement for GE



FRONT CORNER

BACK CORNER


Part No. **WR24X446**
Door Gasket (Fresh Food, White)
 8" W x 32" L
 Replacement for GE



FRONT CORNER

BACK CORNER

Part No. **WR24X449**
Door Gasket (Freezer, White)
 19-1/4" W x 27-1/2" L
 Replacement for GE



FRONT CORNER

BACK CORNER

Part No. **WR24X450**
Door Gasket (Fresh Food, White)
 8" W x 32" L
 Replacement for GE



FRONT CORNER

BACK CORNER


Part No. **WR24X10186**
Door Gasket (Fresh Food, White)
 11-7/8" W x 30-1/2" L
 Replacement for GE



FRONT CORNER

BACK CORNER

Part No. **WR24X10228**
Door Gasket (Freezer, White)
 11-3/4" W x 30-1/2" L
 Replacement for GE



FRONT CORNER

BACK CORNER


Part No. **WR24X10229**
Door Gasket (Fresh Food, White)
 12" W x 30-1/2" L
 Replacement for GE



FRONT CORNER

BACK CORNER

Part No. **WR24X10231**
Door Gasket (Fresh Food, White)
 11-3/4" W x 30-1/2" L
 Replacement for GE



FRONT CORNER

BACK CORNER

Part No. **WR24X10236**
Door Gasket (Fresh Food, White)
 12" W x 30-1/2" L
 Replacement for GE




Part No. **WR2X9144**
Endcap
 Replacement for GE

REFRIGERATION



Part No. **2183141**
Endcap (Handle)
 Replacement for Whirlpool



Part No. **2169142**
Fan Blade
 Replacement for Electrolux



Part No. **5304506469**
Handle Set
 Replacement for Electrolux



Part No. **5304506471**
Handle Set
 Replacement for Electrolux



Part No. **PU410**
Hard Start System
 120V, 1/4 and 1/3 HP
 Will work with or without a run capacitor




Part No. **819043**
Heat Probe
 Replacement for Whirlpool




Part No. **WR13X10020**
Hinge Pin
 Replacement for GE




Part No. **241798224**
Ice Maker
 Replacement for Electrolux



Part No. **243297606**
Ice Maker
 Replacement for Electrolux



Part No. **5303918277**
Ice Maker
 Replacement for Electrolux



Part No. **5303918344**
Ice Maker
 Replacement for Electrolux




Part No. **AEQ36756901**
Ice Maker
 Replacement for LG



Part No. **DA97-00258C**
Ice Maker
 Replacement for mechanical unit only, does not include ice tray
 Replacement for Samsung



Part No. **DA97-11092B**
Ice Maker
 Replacement for Samsung



Part No. **GEIM**
Ice Maker
 Replacement for GE



Part No. **W10190961**
Ice Maker
 Replacement for Whirlpool




Part No. **WIM**
Ice Maker
 Replacement for Whirlpool



Part No. **WR30X10093**
Ice Maker
 Replacement for GE



Part No. **WR17X11705**
Ice Maker Auger
 Replacement for GE



Part No. **4389102**
Ice Maker Board
 Replacement for Whirlpool



Part No. **241675701**
Ice Maker Solenoid
 Replacement for Electrolux



Part No. **WR62X10055**
Ice Maker Solenoid
 Replacement for GE



Part No. **D7813010**
Ice Maker Wiring Harness
 Replacement for Whirlpool



Part No. **18806**
Light Switch

REFRIGERATION



Part No. **2212363**
Motor (Auger)
 Replacement for Whirlpool



Part No. **2252130**
Motor (Auger)
 Replacement for Whirlpool



Part No. **2315547**
Motor (Auger)
 Replacement for Whirlpool



Part No. **2322580**
Motor (Auger)
 Replacement for Whirlpool




Part No. **24221501**
Motor (Auger)
 Replacement for Electrolux



Part No. **W10271506**
Motor (Auger)
 Replacement for Whirlpool



Part No. **WR60X10258**
Motor (Auger)
 Replacement for GE



Part No. **4681JB1029D**
Motor (Condensor)
 13V, 120mA, CCW, 2" shaft
 Replacement for LG



Part No. **W10124096**
Motor (Condensor)
 115V, 4.1W, 60Hz, 1-3/8" shaft
 Replacement for Whirlpool



Part No. **WR60X10168**
Motor (Condensor)
 115V, 60 Hz, 11W, .193A, 2200RPM, 1-3/4" shaft
 Replacement for GE



Part No. **WR60X10209**
Motor (Condensor)
 115V, 2.2W, 2" shaft
 Replacement for GE




Part No. **WR60X10220**
Motor (Condensor)
 115V, 60 Hz, .29A, 3000RPM, 1-3/8" shaft
 Replacement for GE



Part No. **WR60X10348**
Motor (Condensor)
 115V, 60 Hz, 2" shaft
 Replacement for GE



Part No. **4681JB1027C**
Motor (Evaporator)
 13VDC, 3.1W, .24A, 1-7/8" shaft
 Replacement for LG



Part No. **482469**
Motor (Evaporator)
 120V, 60 Hz, .29A, 3000 RPM, 3/4" shaft
 Replacement for Whirlpool



Part No. **482731**
Motor (Evaporator)
 120V, 60 Hz, .26A, 3000 RPM, 3/4" shaft
 Replacement for Whirlpool



Part No. **2315549**
Motor (Evaporator)
 115V, 60 Hz, 1-3/4" shaft
 Replacement for Whirlpool



Part No. **4389144**
Motor (Evaporator)
 120V, 60 Hz, .14A, 3000 RPM, 1-3/8" shaft
 Replacement for Whirlpool



Part No. **12002744**
Motor (Evaporator)
 120V, 60 Hz, .14A, 3000 RPM, 1-3/8" shaft
 Replacement for Whirlpool




Part No. **61004888**
Motor (Evaporator)
 120V, 60 Hz, .21A, 3000 RPM, 1-1/8" shaft
 Replacement for Whirlpool



Part No. **61005935**
Motor (Evaporator)
 120V, 60 Hz, .21A, 3000 RPM, 1-1/8" shaft
 Replacement for Whirlpool



Part No. **240369701**
Motor (Evaporator)
 120V, 60 Hz, .135A, 3000 RPM, 1-3/4" shaft
 Replacement for Electrolux



Part No. **241509402**
Motor (Evaporator)
 1-3/4" shaft
 Replacement for Electrolux



Part No. **241854301**
Motor (Evaporator)
 120V, 60 Hz, .1A, 6W, 1-3/4" shaft
 Replacement for Electrolux




Part No. **242219204**
Motor (Evaporator)
 115V, 60 Hz, .3.3W, 2600RPM, 1-3/4" shaft
 Replacement for Electrolux



Part No. **297250000**
Motor (Evaporator)
 115V, 60 Hz, .18A, 8W, 1-1/4" shaft
 Replacement for Electrolux



Part No. **808602601**
Motor (Evaporator)
 120V, 60 Hz, .1A, 6W, 1-7/8" shaft
 Replacement for Electrolux



Part No. **5300158289**
Motor (Evaporator)
 120V, 60 Hz, .28A, 3000RPM, 1-3/8" shaft
 Replacement for Electrolux



Part No. **5303918549**
Motor (Evaporator)
 120V, 60 Hz, .1A, 6W, 1-3/4" shaft
 Replacement for Electrolux



Part No. **DA31-00146B**
Motor (Evaporator)
 12VDC, 2.5W, .21A, 1550RPM, 1-3/4" shaft
 Replacement for Samsung



Part No. **DA31-00146E**
Motor (Evaporator)
 12VDC, 3.21W, 2520RPM, 1-1/2" shaft
 Replacement for Samsung



Part No. **DA31-00146H**
Motor (Evaporator)
 12VDC, 2.1W, 0.176A, 2950RPM, 1-1/2" shaft
 Replacement for Samsung



Part No. **DA31-00146J**
Motor (Evaporator)
 12VDC, 2.8W, 1920RPM, 2" shaft
 Replacement for Samsung



Part No. **EAU61524007**
Motor (Evaporator)
 13V, 1.5W, 0.118A, 1-1/2" shaft
 Replacement for LG



Part No. **M245**
Motor (Evaporator)
 CW/CCW Rotation, 1-3/4" shaft
 Universal Replacement



Part No. **M249**
Motor (Evaporator)
 CW/CCW Rotation, Breakaway shaft
 Universal Replacement



Part No. **W10128551**

Motor (Evaporator)
115V, 60 Hz, .14A, 1-3/8" shaft
Replacement for Whirlpool



Part No. **W10188389**

Motor (Evaporator)
120V, 60 Hz, .12A, 2950RPM, 7/8" shaft
Replacement for Whirlpool



Part No. **W10189703**

Motor (Evaporator)
120V, 60 Hz, .135A, 3000RPM, 1" shaft
Replacement for Whirlpool



Part No. **WR60X162**

Motor (Evaporator)
120V, 60 Hz, .135A, 3000RPM, 1-5/8" shaft
Replacement for GE



Part No. **WR60X190**

Motor (Evaporator)
120V, 60 Hz, .25A, 3000RPM, 1-3/8" shaft
Replacement for GE



Part No. **WR60X203**

Motor (Evaporator)
120V, 60 Hz, .21A, 3000RPM, 1-1/2" shaft
Replacement for GE



Part No. **WR60X10074**

Motor (Evaporator)
9.75VDC, 3.25W, 2-3/8" shaft
Replacement for GE



Part No. **WR60X10141**

Motor (Evaporator)
115V, 60 Hz, 3W, 1-5/8" shaft
Replacement for GE



Part No. **WR60X10172**

Motor (Evaporator)
115V, 60 Hz, .2A, 2800RPM, 2-5/8" shaft
Replacement for GE



Part No. **WR60X10185**

Motor (Evaporator)
9.75VDC, 3.25W, 2-3/8" shaft
Replacement for GE



Part No. **WR60X10307**

Motor (Evaporator)
9.75VDC, 3.25W, 2-3/8" shaft
Replacement for GE



Part No. **WR60X26085**

Motor (Evaporator)
115V, 60 Hz, 1-1/4" shaft
Replacement for GE

REFRIGERATION



Part No. **EAU64824401**
Motor (Fan)
 Replacement for LG



Part No. **M670**
Motor (Utility)
 120V, 60 Hz, .55A, 3000RPM, 1-1/4" shaft
 Universal Replacement



Part No. **DA81-06013A**
Motor Fan
 Replacement for Samsung



Part No. **2188829**
Overload/Relay
 Used on 22 cubic foot refrigerators
 Replacement for Whirlpool



Part No. **2188830**
Overload/Relay
 Used on 25 cubic foot refrigerators and larger
 Replacement for Whirlpool



Part No. **4387913**
Overload/Relay Kit
 Replacement for Whirlpool



Part No. **12555902**
Overload
 Replacement for Whirlpool



Part No. **61005518**
Overload/Relay
 Replacement for Whirlpool



Part No. **WR07X10131**
Overload/PTCR Relay
 Replacement for GE



Part No. **WR09X10106**
Overload/PTCR Relay
 Replacement for GE



Part No. **WR09X10107**
Overload/PTCR Relay
 Replacement for GE




Part No. **P410**
Power Start System
 120V, 1/4 and 1/3 HP



Part No. **P810**
Power Start System
 120V, 1/2 thru 1/5 HP



Part No. **IC102**
Relay



Part No. **8201786**
Start Device Kit
 Replacement for Whirlpool



Part No. **W10613606**
Start Device
 Replacement for Whirlpool



Part No. **ADH73150210**
Spun Copper Drier
 Replacement for LG



Part No. **D109**
Spun Copper Drier (Non-directional)
 1/4" inlet, 1/4" outlet, 3/4" diameter
 Recommended tonnage: (R-12)3/4 (R-22)1/2
 Economy with extended and fused ends



Part No. **D111**
Spun Copper Drier (Directional)
 1/4" inlet, Cap + 1/4" outlet
 1" diameter, 3/16" process tube
 Recommended tonnage: (R-12)1-1/2 (R-22)3/4
 Heavy duty with Schrader to evacuate or charge the system, fused and scored ends



Part No. **D115**
Spun Copper Drier (Directional)
 1/4" inlet, Cap + 1/4" outlet
 3/4" diameter, 3/16" process tube
 Recommended tonnage: (R-12)3/4 (R-22)1/2
 Economy with Schrader to evacuate or charge the system, fused and scored ends



Part No. **41008**
Surge Protector



Part No. **240597203**
Temperature Sensor
 Replacement for Electrolux



Part No. **6615JB2005H**
Temperature Sensor
 Replacement for LG



Part No. **DA32-00006S**
Temperature Sensor
 Replacement for Samsung


REFRIGERATION



Part No. **DA32-00006W**
Temperature Sensor
Replacement for Samsung



Part No. **DA32-10104N**
Temperature Sensor
Replacement for Samsung



Part No. **DA32-10105X**
Temperature Sensor
Replacement for Samsung



Part No. **WR55X10025**
Temperature Sensor
Replacement for GE



Part No. **W10316760**
Thermistor
Replacement for Whirlpool



Part No. **W10383615**
Thermistor
Replacement for Whirlpool



Part No. **241685703**
Water Dispenser Actuator
Replacement for Electrolux



Part No. **4396508**
Water Filter
Replacement for Whirlpool



Part No. **5231JA2006B**
Water Filter
Replacement for LG



Part No. **ADQ36006102**
Water Filter
Replacement for LG



Part No. **DA29-00003G**
Water Filter
Replacement for Samsung



Part No. **DA29-00020B**
Water Filter
Replacement for Samsung



Part No. **SS08**
Water Filter
Replacement for GE



Part No. **UKF8001**
Water Filter
Replacement for Whirlpool



Part No. **WF1CB**
Water Filter
Replacement for Electrolux



Part No. **WF271**
Water Filter
Replacement for Whirlpool



Part No. **WFCB**
Water Filter
Replacement for Electrolux



Part No. **5220JA2009D**
Water Valve
Replacement for LG



Part No. **5221JA2006D**
Water Valve
Replacement for LG



Part No. **5221JB2006A**
Water Valve
Replacement for LG



Part No. **759296**
Water Valve
Replacement for Whirlpool



Part No. **2315576**
Water Valve
Replacement for Whirlpool



Part No. **61005273**
Water Valve
Replacement for Whirlpool



Part No. **61005626**
Water Valve
Replacement for Whirlpool

REFRIGERATION



Part No. **67003753**
Water Valve
 Replacement for Whirlpool



Part No. **67005154**
Water Valve
 Replacement for Whirlpool



Part No. **67006531**
Water Valve
 Replacement for Whirlpool



Part No. **242252603**
Water Valve
 Replacement for Electrolux



Part No. **242252702**
Water Valve
 Replacement for Electrolux



Part No. **242253002**
Water Valve
 Replacement for Electrolux



Part No. **AJU72992601**
Water Valve
 Replacement for LG



Part No. **DA62-02360B**
Water Valve
 Replacement for Samsung



Part No. **MJX41178908**
Water Valve
 Replacement for LG



Part No. **W10179146**
Water Valve
 Replacement for Whirlpool



Part No. **W10238100**
Water Valve
 Replacement for Whirlpool



Part No. **W10258562**
Water Valve
 Replacement for Whirlpool



Part No. **W10279866**
Water Valve
Replacement for Whirlpool



Part No. **W10279909**
Water Valve
Replacement for Whirlpool



Part No. **W10312696**
Water Valve
Replacement for Whirlpool



Part No. **W10341320**
Water Valve
Replacement for Whirlpool



Part No. **W10341329**
Water Valve
Replacement for Whirlpool



Part No. **W10394076**
Water Valve
Replacement for Whirlpool



Part No. **W10408179**
Water Valve
Replacement for Whirlpool



Part No. **W10420083**
Water Valve
Replacement for Whirlpool



Part No. **W10498976**
Water Valve
Replacement for Whirlpool



Part No. **W10853654**
Water Valve
Replacement for Whirlpool




Part No. **W11043013**
Water Valve
Replacement for Whirlpool



Part No. **WR57X77**
Water Valve
Replacement for GE

REFRIGERATION



Part No. **WR57X10023**
Water Valve
Replacement for GE




Part No. **WR57X10024**
Water Valve
Replacement for GE



Part No. **WR57X10033**
Water Valve
Replacement for GE



Part No. **WR57X10051**
Water Valve
Replacement for GE



Part No. **WR71X2086**
Wire Rack
Replacement for GE



Part No. **240360906**
Wire Shelf
Replacement for Electrolux



Part No. **W10006355**
Actuator
 Replacement for Whirlpool



Part No. **W10913953**
Actuator
 Replacement for Whirlpool




Part No. **W10352973**
Actuator (Dispenser)
 Replacement for Whirlpool



Part No. **285811**
Agitate Cam Kit
 Replacement for Whirlpool



Part No. **WH49X10042**
Agitate Coupling
 Replacement for GE



Part No. **80040**
Agitate Dogs (4pk)
 Replacement for Whirlpool



Part No. **4413ER1003B**
Assembly Rotor
 Replacement for LG



Part No. **DC31-00112A**
Assembly Rotor
 Replacement for Samsung



Part No. **4417EA1002K**
Assembly Stator
 Replacement for LG



Part No. **285792**
Basket Drive
 Replacement for Whirlpool



Part No. **MAP61913708**
Bearing
 2-7/8" diameter
 Replacement for LG



Part No. **MAP61913727**
Bearing
 2-1/2" diameter
 Replacement for LG



Part No. **W10435302**

Bearing

Replacement for Whirlpool



Part No. **211124**

Belt

Replacement for Whirlpool



Part No. **211125**

Belt

Replacement for Whirlpool



Part No. **8540101**

Belt

Replacement for Whirlpool



Part No. **21352320**

Belt

Replacement for Whirlpool



Part No. **22003483**

Belt

Replacement for Whirlpool



Part No. **27001006**

Belt

Replacement for Whirlpool



Part No. **131686100**

Belt

Replacement for Electrolux



Part No. **W10006384**

Belt

Replacement for Whirlpool



Part No. **W10260319**

Belt

Replacement for Whirlpool



Part No. **WH01X10302**

Belt

Replacement for GE



Part No. **WH08X10024**

Belt

Replacement for GE




Part No. **WH08X10050**
Belt
 Replacement for GE



Part No. **12112425**
Belt Kit
 Replacement for Whirlpool



Part No. **WH1X2727**
Bungee Cord
 Replacement for GE



Part No. **00154740**
Carbon Brush (2pk)
 Replacement for Bosch



Part No. **285785**
Clutch Assembly
 Replacement for Whirlpool



Part No. **W10189966**
Control Board (Refurbished)
 Replacement for Whirlpool



Part No. **285753**
Coupler (Drive)
 Replacement for Whirlpool



Part No. **285753A**
Coupler (Drive)
 Has metal inserts
 Replacement for Whirlpool



Part No. **285852**
Coupler (Heavy Duty)
 Replacement for Whirlpool



Part No. **426862P**
Diverter Valve
 Replacement for Fisher Paykel



Part No. **00772658**
Door Boot
 Replacement for Bosch



Part No. **4986ER0004G**
Door Boot
 Replacement for LG



Part No. **706276**

Door Boot

Replacement for Bosch



Part No. **8182119**

Door Boot

Replacement for Whirlpool



Part No. **DC64-00802AB**

Door Boot

Replacement for Samsung



Part No. **MDS47123605**

Door Boot

Replacement for LG



Part No. **4775ER2002A**

Door Hinge

Replacement for LG



Part No. **W10721967**

Drive Splutch Kit

Replacement for Whirlpool



Part No. **8181846**

Handle

Replacement for Whirlpool



Part No. **3804FF**

Hose (Fill)

4 ft. female x female



Part No. **3805FF**

Hose (Fill)

5 ft. female x female



Part No. **3806FF**

Hose (Fill)

6 ft. female x female



Part No. **3806MF**

Hose (Fill)

6 ft. male x female



Part No. **3815FF**

Hose (Fill)

15 ft. female x female



Part No. **4738ER1002A**

Hose
Replacement for LG



Part No. **SSD6**

Hose (Drain)
1" x 6 ft.



Part No. **SSD8**

Hose (Drain)
1" x 8 ft.



Part No. **WDH6FT**

Hose (Drain)
6 ft.



Part No. **WH1X2754**

Knob
1-7/8" diameter
Replacement for GE



Part No. **WH01X10310**

Knob
2" diameter, 1/2" ext. shaft
Replacement for GE



Part No. **WH01X10460**

Knob
1-7/8" diameter, 1/8" ext. shaft
Replacement for GE



Part No. **6601ER1004C**

Latch (Door/Lid)
Replacement for LG



Part No. **131763202**

Latch (Lid)
Replacement for Electrolux



Part No. **W10404050**

Latch Assembly
Replacement for Whirlpool



Part No. **49621**

Leveling Leg
Replacement for Whirlpool



Part No. **285671**

Lid Switch
Replacement for Whirlpool



Part No. **3355806**
Lid Switch
Replacement for Whirlpool



Part No. **3949238**
Lid Switch
Replacement for Whirlpool



Part No. **3949247**
Lid Switch
Replacement for Whirlpool



Part No. **8318084**
Lid Switch
Replacement for Whirlpool



Part No. **EBF61674802**
Lid Switch
Replacement for LG



Part No. **W10820036**
Lid Switch
Replacement for Whirlpool




Part No. **WH12X10334**
Lid Switch
Replacement for GE



Part No. **203504**
Lock (Door)
Replacement for Alliance



Part No. **802317P**
Lock (Door)
Replacement for Speedqueen



Part No. **134936800**
Lock (Door)
Replacement for Electrolux



Part No. **EBF49827801**
Lock (Door)
Replacement for LG



Part No. **EBF61315802**
Lock (Door)
Replacement for LG



Part No. **DC34-00024B**
Lock (Door)
 Replacement for Samsung



Part No. **W10192995**
Lock (Door)
 Replacement for Whirlpool



Part No. **WH10X10006**
Lock (Door)
 Replacement for GE



Part No. **137353302**
Lock (Lid)
 Replacement for Electrolux



Part No. **WH44X10288**
Lock (Lid)
 Replacement for GE



Part No. **W10278117**
Motor Run Capacitor
 Replacement for Whirlpool



Part No. **W10278556**
Motor Run Capacitor
 Replacement for Whirlpool



Part No. **KP-2**
Pliers (Hose Clamp)
 Service tool for double ring wire clamps
 Plier locks clamp in jaw



Part No. **THP-1**
Pliers (Hose)
 8-3/4" length
 Great for washers with indented water valves



Part No. **134762010**
Pressure Switch
 Replacement for Electrolux



Part No. **DC96-01703B**
Pressure Switch
 Replacement for Samsung



Part No. **WH12X10412**
Pressure Switch
 Replacement for GE



Part No. **WH12X10476**
Pressure Switch
Replacement for GE



Part No. **25001052**
Pump (Drain)
Replacement for Whirlpool



Part No. **34001098**
Pump (Drain)
Replacement for Whirlpool



Part No. **34001320**
Pump (Drain)
Replacement for Whirlpool



Part No. **34001340**
Pump (Drain)
Replacement for Whirlpool



Part No. **137311900**
Pump (Drain)
Replacement for Electrolux



Part No. **DC31-00054A**
Pump (Drain)
Replacement for Samsung



Part No. **DC31-00054D**
Pump (Drain)
Replacement for Samsung



Part No. **DC96-01414A**
Pump (Drain)
Replacement for Samsung



Part No. **DC96-01700A**
Pump (Drain)
Replacement for Samsung



Part No. **W10409079**
Pump (Drain)
Replacement for Whirlpool



Part No. **W10465252**
Pump (Drain)
Replacement for Whirlpool



Part No. **W10661045**
Pump (Drain)
Replacement for Whirlpool



Part No. **W10876600**
Pump (Drain)
Replacement for Whirlpool



Part No. **W10919003**
Pump (Drain)
Replacement for Whirlpool



Part No. **4681EA2001T**
Pump
Replacement for LG



Part No. **4681EA2002H**
Pump
Replacement for LG



Part No. **280187**
Pump
Replacement for Whirlpool



Part No. **3363394**
Pump
Replacement for Whirlpool



Part No. **3363892**
Pump
Replacement for Whirlpool



Part No. **21001906**
Pump
Replacement for Whirlpool



Part No. **21002240**
Pump
Replacement for Whirlpool



Part No. **137108000**
Pump
Replacement for Electrolux



Part No. **137221600**
Pump
Replacement for Electrolux



Part No. **137240800**
Pump
Replacement for Electrolux



Part No. **5304514769**
Pump
Replacement for Electrolux



Part No. **W10130913**
Pump
Replacement for Whirlpool



Part No. **W10276397**
Pump
Replacement for Whirlpool



Part No. **W10391443**
Pump
Replacement for Whirlpool



Part No. **W10425238**
Pump
Replacement for Whirlpool



Part No. **W10536347**
Pump
Replacement for Whirlpool



Part No. **W10581874**
Pump
Replacement for Whirlpool



Part No. **W10730972**
Pump
Replacement for Whirlpool




Part No. **WH23X10028**
Pump
Replacement for GE



Part No. **WH23X10030**
Pump
Replacement for GE




Part No. **280187MTR**
Pump Motor
Replacement for Whirlpool



Part No. **DC31-00098A**
Sensor
 Replacement for Samsung



Part No. **6501KW2002A**
Sensor (Motor)
 Replacement for LG



Part No. **DC93-00278B**
Sensor (Vibration)
 Replacement for Samsung



Part No. **00642112**
Shock Absorber
 Replacement for Bosch



Part No. **00742719**
Shock Absorber
 Replacement for Bosch



Part No. **383ER3001V**
Shock Absorber
 Replacement for LG



Part No. **8182703**
Shock Absorber
 Replacement for Whirlpool



Part No. **5304485917**
Shock Absorber
 Replacement for Electrolux



Part No. **DC66-00343A**
Shock Absorber
 Replacement for Samsung



Part No. **DC66-00470A**
Shock Absorber
 Replacement for Samsung



Part No. **DC66-00470B**
Shock Absorber
 Replacement for Samsung



Part No. **W10822553**
Shock Absorber
 Replacement for Whirlpool



Part No. **W10869845**
Stacking Kit
Replacement for Whirlpool



Part No. **131763310**
Striker
Replacement for Electrolux



Part No. **DC97-05280S**
Suspension Rod
Replacement for Samsung



Part No. **DC97-05280W**
Suspension Rod
Replacement for Samsung



Part No. **DC97-16350C**
Suspension Rod
Replacement for Samsung



Part No. **DC97-16350E**
Suspension Rod
Replacement for Samsung



Part No. **W10247710**
Suspension Kit
Replacement for Whirlpool



Part No. **W10780045**
Suspension Kit
Replacement for Whirlpool



Part No. **W10780048**
Suspension Kit
Replacement for Whirlpool



Part No. **W10820048**
Suspension Kit
Replacement for Whirlpool



Part No. **DC90-10128N**
Thermistor
Replacement for Samsung



Part No. **383727**
Tub Grommet
Replacement for Whirlpool




Part No. **TB 123A**
Tub Nut Wrench
Removes tub nut from washing machines



Part No. **WM0612N**
Washer Magic
(Sold in 6PK case ONLY)
Removes lime scale, soap scum & iron stains
Safe for plumbing & septic systems



Part No. **343**
Water Valve
Universal Replacement



Part No. **525**
Water Valve
Universal Replacement



Part No. **5220FR2006H**
Water Valve
Replacement for LG



Part No. **5220FR2008C**
Water Valve
Replacement for LG



Part No. **5220FR2008F**
Water Valve
Replacement for LG



Part No. **5220FR2075C**
Water Valve
Replacement for LG



Part No. **5221ER1003A**
Water Valve
Replacement for LG



Part No. **201468P**
Water Valve
Replacement for Speedqueen



Part No. **422244**
Water Valve
Replacement for Bosch



Part No. **422245**
Water Valve
Replacement for Bosch



Part No. **3979346**
Water Valve
Replacement for Whirlpool



Part No. **8181694**
Water Valve
Replacement for Whirlpool



Part No. **8182862**
Water Valve
Replacement for Whirlpool



Part No. **8540751**
Water Valve
Replacement for Whirlpool



Part No. **134211400**
Water Valve
Replacement for Electrolux



Part No. **134371220**
Water Valve
Replacement for Electrolux



Part No. **134637810**
Water Valve
Replacement for Electrolux



Part No. **134959340**
Water Valve
Replacement for Electrolux



Part No. **AJU75152601**
Water Valve
Replacement for LG



Part No. **DC62-00142G**
Water Valve
Replacement for Samsung



Part No. **DC62-00214M**
Water Valve
Replacement for Samsung



Part No. **DC62-30312J**
Water Valve
Replacement for Samsung



Part No. **DC62-30314K**
Water Valve
Replacement for Samsung



Part No. **DC97-15459D**
Water Valve
Replacement for Samsung



Part No. **DC97-15459G**
Water Valve
Replacement for Samsung



Part No. **DC97-15459H**
Water Valve
Replacement for Samsung



Part No. **W10144820**
Water Valve
Replacement for Whirlpool



Part No. **W10212596**
Water Valve
Replacement for Whirlpool



Part No. **W10212598**
Water Valve
Replacement for Whirlpool



Part No. **W10247306**
Water Valve
Replacement for Whirlpool



Part No. **W10326913**
Water Valve
Replacement for Whirlpool



Part No. **W10683603**
Water Valve
Replacement for Whirlpool



Part No. **W11096267**
Water Valve
Replacement for Whirlpool



Part No. **W11168740**
Water Valve
Replacement for Whirlpool



Part No. **W11168743**
Water Valve
Replacement for Whirlpool



Part No. **W11220230**
Water Valve
Replacement for Whirlpool



Part No. **WH13X10024**
Water Valve
Replacement for GE



Part No. **WH13X10025**
Water Valve
Replacement for GE



Part No. **WH13X10026**
Water Valve
Replacement for GE



Part No. **WH13X10027**
Water Valve
Replacement for GE



Part No. **WH13X10029**
Water Valve
Replacement for GE



Part No. **WH13X10037**
Water Valve
Replacement for GE



Part No. **WH13X10048**
Water Valve
Replacement for GE



Part No. **WH13X22314**
Water Valve
Replacement for GE



Part No. **WH13X22720**
Water Valve
Replacement for GE



Part No. **WH13X25296**
Water Valve
Replacement for GE



Part No. **WH13X26535**
Water Valve
Replacement for GE



Part No. **WV-1**
Water Valve
Universal Replacement



Part No. **WV-2**
Water Valve
Universal Replacement

INDEX

00154740	81	971KIT	52	7212P043-60	18	819043	66
00167085	31	1003	51	7403P23960	12	902894	31
00436440	32	1090	50	7431P2760K	22	903758	50
00494772	30	1126	20	7737P245-60	14	1013833	51
00611332	32	1153KIT	39	8504	8	1474052P	50
00611666	33	1398	6	18806	67	2159057	62
00620774	32	1408	50	41008	73	2159061	62
00628334	35	1409	50	49621	83	2159327	62
00642112	89	1438	20	56120	21	2169142	66
00652184	44	1440	20	61927	40	2183141	66
00742719	89	1801M58	6	80040	79	2183400	59
00754866	30	1801M59	7	110222	41	2188829	72
00754873	30	1802A206	20	165314	33	2188830	72
00772658	81	1842A57	28	189324	10	2188436A	62
0130F00010KIT	50	1999	20	201468P	91	2188448A	62
02532625000	50	2167	28	203504	84	2188462A	62
6-3700340	42	2168	28	211124	80	2198202	57
10C7	2	3412A004-19	6	211125	80	2200859	57
10QBP0228	54	3700KIT2	45	279311	42	2212363	68
10QBP0229	54	3804FF	82	279393	45	2252130	68
10QBP0230	54	3805FF	82	279408	39	2262080	63
10QBP0231	55	3806FF	82	279570	38	2263749	58
10QBP0232	55	3806MF	82	279570M	38	2315547	68
10QBP0234	55	3815FF	82	279640	42	2315549	69
10QBP0235	55	3920DD3005A	31	279735	40	2315576	75
10QBP1000	55	4400EL2001A	37	279769	47	2319264T	63
10QBP1003	55	4413ER1003B	79	279816	47	2319265T	63
10QBP1004	55	4417EA1002K	79	279838	40	2319266T	63
10QBP1006	55	4560EL3001A	41	279973	47	2322580	68
11QBP0236	53	4561EL3002A	42	280187	87	2323198	58
11QBPUNIV	54	4581EL2002A	46	280187MTR	88	3148952	11
13QBP21090	53	4581EL2002C	46	285671	83	3148953	11
13QBP21095	53	4581KIT4	45	285753	81	3149400	11
13QBP21100	53	4681EA2001T	87	285753A	81	3149404	11
13QBP21105	53	4681EA2002H	87	285785	81	3181304	14
14QBP20CFB	53	4681JB1027C	69	285792	79	3196803	28
14QBP20CSB	53	4681JB1029D	68	285811	79	3203459	21
25QBP3779	54	4738ER1002A	83	285852	81	3204267	48
25QBP3780	54	4750	54	303373K	46	3355806	84
25QBP3784	54	4775ER2002A	82	303404	40	3363394	87
25QBP3785	54	4986ER0004G	81	303836	38	3363892	87
26QBP0213	53	5220FR2006H	91	312959	37	3387134	48
26QBP0264	53	5220FR2008C	91	318984-753	51	3387747	40
26QBP0930	53	5220FR2008F	91	330031	27	3390719	47
26QBP3236	53	5220FR2075C	91	338906	41	3392519	47
26QBP4076	53	5220JA2009D	75	339392	44	3394652	37
26QBP4093	53	5221ER1003A	91	341241	37	3399849	47
28QBP0491	56	5221JA2006D	75	349241	46	3406105	39
28QBP0495	56	5221JB2006A	75	349241T	46	3406107	39
28QBP0496	56	5231EL1003B	44	349639	44	3406108	39
28QBP0497	56	5231JA2006B	74	383727	90	3949238	84
28QBP0499	56	5301EL1001G	40	422244	91	3949247	84
30QBP0663	56	5318EL3001A	42	422245	91	3977767	48
30QBP1848	56	5817S0007	21	425458	35	3979346	92
30QBP4185	56	6286W	14	426862P	81	4334809	18
34FHT	32	6501KW2002A	89	482469	69	4387490	60
40A15	2	6513S0001	21	482731	69	4387503	60
40QBP1012	56	6520S0201	21	490467	30	4387913	72
40T61/2	2	6540S0001	21	607335	35	4389102	67
53-0918	44	6544S0001	21	611475	33	4389144	69
60J00	51	6545S0001	21	622058	35	4391960	40
98QBP0300	56	6547S0001	21	642239	32	4392065	45
98QBP0302	56	6549S0001	21	644424	9	4392067	45
98QBP0303	56	6601EL3001A	38	661566	35	4396508	74
119-4400-5	9	6601ER1004C	83	661658	32	5500200	11
197	47	6602-001655	37	675813	34	5500200M	11
343	91	6615JB2005H	73	691366	42	5500202M	11
383EER3001V	89	6700S0011	28	694089	38	5502404	12
525	91	6931EL3001E	48	706276	82	6610341	22
944KIT	51	6931EL3003C	48	759296	75	8181694	92
947KIT	52	6931EL3003D	48	802317P	84	8181846	82

INDEX

8182119.....	82	67002493.....	58	241872505.....	64	5304506516.....	34
8182703.....	89	67003426.....	61	241872509.....	64	5304507386.....	15
8182862.....	92	67003753.....	76	241872510.....	64	5304509929.....	15
8193762.....	34	67005154.....	76	241872512.....	64	5304513033.....	57
8194001.....	32	67006531.....	76	241872513.....	64	5304514769.....	88
8201786.....	73	71001641.....	14	241872514.....	64	5304516159.....	24
8268383.....	30	74002390.....	28	241993001.....	58	5304516160.....	24
8268743.....	33	74003332.....	6	242044020.....	58	5304518660.....	18
8269145.....	30	74005019.....	28	242044113.....	58	5304518661.....	18
8273106.....	14	74007733.....	14	242219204.....	70	5304518927.....	34
8273992.....	25	74010141.....	18	242221501.....	68	A00126401.....	32
8318084.....	84	74010205.....	14	242252603.....	76	A00126501.....	32
8523793.....	10	74010839.....	14	242252702.....	76	ADH73150210.....	73
8531669.....	35	74011260.....	14	242253002.....	76	ADQ36006102.....	74
8531964.....	44	74011287.....	14	243297606.....	66	AEQ36756901.....	66
8540101.....	80	97012038.....	17	297250000.....	70	AJU72992601.....	76
8540751.....	92	97012248.....	17	316032411.....	28	AJU75152601.....	92
8544742.....	37	98003984.....	28	316039002.....	6	B0750.....	2
8544771.....	40	131686100.....	80	316039003.....	7	B1094.....	3
8547157.....	37	131763202.....	83	316067902.....	18	B1117.....	3
8547174.....	42	131763310.....	90	316091706.....	20	B1401018S.....	51
8557884.....	45	134120900.....	47	316102303.....	16	B1551.....	5
8561996.....	34	134211400.....	92	316103802.....	6	B1859005.....	51
8577274.....	48	134371220.....	92	316103803.....	7	B2200.....	3
9755542.....	27	134637810.....	92	316215900.....	28	B2395.....	3
9758079.....	11	134715900.....	46	316215901.....	28	B3200.....	5
9759242.....	27	134719300.....	37	316217002.....	19	B3301.....	5
9759243.....	27	134762010.....	85	316220000.....	14	B3800.....	3
10359708Q.....	63	134792700.....	40	316220008.....	14	B4107.....	3
12001541.....	46	134844470.....	43	316220009.....	15	B5002.....	3
12001596.....	22	134886700.....	43	316233902.....	19	B5103.....	3
12001655.....	19	134936800.....	84	316238201.....	12	B5900.....	3
12001656.....	19	134959340.....	92	316238202.....	12	B68C.....	38
12001676.....	27	137032600.....	47	316239700.....	18	B7019.....	3
12002744.....	69	137051400.....	37	316270200.....	7	B7340.....	5
12004485.....	33	137108000.....	87	316270201.....	7	B7646.....	3
12112425.....	81	137114000.....	41	316282000.....	25	B775.....	2
12550109Q.....	63	137221600.....	87	316353104.....	15	B777.....	2
12550111Q.....	63	137240800.....	88	316436000.....	12	B778.....	2
12550115Q.....	63	137292700.....	37	316436001.....	12	B779.....	5
12550116Q.....	63	137311900.....	86	316496201.....	18	B790.....	2
12555902.....	72	137353302.....	85	316543907.....	15	B837.....	2
20165703S.....	50	137539200.....	47	316564509.....	15	B8541.....	3
21001906.....	87	137544800.....	43	318099104.....	15	B856.....	2
21002240.....	87	154430501.....	34	318601604.....	25	D109.....	73
21352320.....	80	154568001.....	34	622266992.....	50	D111.....	73
22003483.....	80	154580301.....	32	807004702.....	12	D115.....	73
25001052.....	86	154637401.....	35	807047901.....	35	D7813010.....	67
27001006.....	80	154701001.....	34	808602601.....	70	DA29-00003G.....	74
31001556.....	42	154825001.....	30	808608801.....	22	DA29-00020B.....	74
33001003.....	45	154827601.....	31	808608802.....	22	DA31-00146B.....	70
33001807.....	41	215366002.....	62	809006501.....	34	DA31-00146E.....	70
33001808.....	45	215846602.....	59	5300158289.....	70	DA31-00146H.....	70
33002032.....	37	218730603.....	63	5300622032.....	41	DA31-00146J.....	70
33002970.....	45	218730605.....	64	5300622034.....	41	DA32-00006S.....	73
34001098.....	86	218969902.....	61	5303281153.....	39	DA32-00006W.....	74
34001320.....	86	240331401.....	62	5303283286.....	41	DA32-10104N.....	74
34001340.....	86	240338001.....	62	5303918202.....	61	DA32-10105X.....	74
37001042.....	46	240360906.....	78	5303918214.....	61	DA47-00243K.....	61
37001287.....	42	240369701.....	69	5303918277.....	66	DA47-00244B.....	58
37001298.....	39	240597203.....	73	5303918344.....	66	DA47-00244D.....	58
40111201.....	37	241509402.....	69	5303918549.....	70	DA47-00285P.....	61
40113801.....	47	241675701.....	67	5303937139.....	39	DA47-00322J.....	58
61001846.....	58	241685703.....	74	5303937182.....	40	DA47-00424A.....	59
61004003.....	63	241705102.....	60	5304404821.....	57	DA47-00424B.....	59
61004008.....	63	241798224.....	66	5304421256.....	57	DA47-00424L.....	59
61004888.....	69	241854301.....	69	5304464438.....	57	DA62-01477A.....	76
61005273.....	75	241872501.....	64	5304477398.....	54	DA62-01585A.....	76
61005518.....	72	241872502.....	64	5304485917.....	89	DA62-02360B.....	76
61005626.....	75	241872503.....	64	5304506469.....	66	DA81-06013A.....	72
61005935.....	69	241872504.....	64	5304506471.....	66	DA97-00258C.....	67

INDEX

DA97-05253B	65	DG47-00066A	25	PU410	66	W10258275	34
DA97-05557Y	65	DG47-00067A	25	R117	27	W10258562	76
DA97-07695A	76	DG62-00067A	7	RS65D12	25	W10260319	80
DA97-07827B	76	DG62-00070A	7	RS85D20	25	W10271506	68
DA97-11092B	67	DG62-00111A	7	RS975D25	25	W10275048	25
DB6GE1	7	DG94-00449A	20	S218	23	W10276397	88
DB6GE2	7	DG94-00520A	9	S219	24	W10278117	85
DB6WH	7	DG94-01012A	9	S30M1	22	W10278150	11
DB8GE1	8	DM06N	30	S30M2	23	W10278556	85
DB8GE2	8	DM24F	30	S348	24	W10279866	77
DB8WH	8	DVC202PK	44	S354	24	W10279909	77
DBU6	8	DWDH78	30	S356	24	W10282492	19
DBU6P	8	EAFCBF	57	S359	24	W10300924V	31
DBU6P1	8	EAU61524007	70	S36Y12	23	W10311986	33
DBU8	8	EAU64824401	72	S46D15	23	W10312696	77
DBU8P	8	EBF49827801	84	S46Y12	23	W10314173	46
DBU8P1	8	EBF61315802	84	S46Y15	23	W10316760	74
DC31-00054A	86	EBF61674802	84	S48D21	23	W10321304	57
DC31-00054D	86	EBZ37189609	15	S48Y21	23	W10324262	11
DC31-00055G	45	EBZ37189611	15	S58D21	23	W10326913	93
DC31-00098A	89	EXT12FT	44	S58D26	23	W10327249	36
DC31-00112A	79	FLTR012	9	S58Y21	23	W10328463	38
DC32-00007A	48	GEIM	67	S58Y26	23	W10331686	22
DC34-00024B	85	GP1	60	SHUBEE	51	W10339442	15
DC47-00016A	47	GP11	60	SKK-7A	46	W10341320	77
DC47-00017A	48	GR403	9	SS08	75	W10341329	77
DC47-00018A	48	H-301	51	SSD6	83	W10348269	33
DC47-00019A	41	H-316	51	SSD8	83	W10352689	58
DC47-00022A	43	IC102	73	TB123A	91	W10352973	79
DC62-00142G	92	IG0001	9	THP-1	85	W10370189	15
DC62-00214M	92	IG10016	10	TR6GE	8	W10380496	18
DC62-30312J	92	IG101	51	TR8GE	8	W10383615	74
DC62-30314K	93	IG21	10	UDI	43	W10391443	88
DC64-00802AB	82	IG35	10	UKF8001	75	W10394076	77
DC64-00828A	39	IG5068	10	W10006355	79	W10402110	35
DC66-00343A	89	IG5652	10	W10006384	80	W10404050	83
DC66-00470A	89	IG9159	10	W10110486	22	W10408179	77
DC66-00470B	89	IG9400	10	W10110491	22	W10409079	86
DC90-10128N	90	IG9998	10	W10120998	44	W10420083	77
DC93-00278B	89	KN001	17	W10124096	68	W10425238	88
DC93-00634A	42	KN002	17	W10128551	71	W10434452	12
DC96-00887A	48	KP-2	85	W10130913	88	W10435302	80
DC96-01414A	86	L290	49	W10131825	19	W10436303	49
DC96-01700A	86	LA1008	46	W10136934	38	W10465252	86
DC96-01703B	85	LA1044	41	W10141709	7	W10490648	17
DC97-05280S	90	LA1053	48	W10144820	93	W10498976	77
DC97-05280W	90	LA11AA005	50	W10158389	36	W10508950	30
DC97-14486A	41	LH680005	51	W10159016	28	W10509257	31
DC97-15459D	93	LH680014	50	W10179146	76	W10510667	33
DC97-15459G	93	M245	70	W10181986	20	W10524469	31
DC97-15459H	93	M249	70	W10185970	49	W10536347	88
DC97-16350C	90	M550	17	W10185976	49	W10537869	30
DC97-16350E	90	M670	72	W10185981	49	W10547292	42
DC97-16782A	46	MAP61913708	79	W10186032	49	W10581874	88
DC97KIT4	46	MAP61913727	79	W10188389	71	W10613606	73
DD31-00005A	32	MDS47123605	82	W10189703	71	W10661045	87
DD31-00016A	33	MEE36593202	4	W10189966	81	W10683603	93
DD32-00005A	35	MEE61841401	10	W10190961	67	W10698166	17
DD62-00043A	31	MEE62306504	4	W10192995	85	W10712394	33
DD62-00067A	35	MJX41178908	76	W10195416	34	W10717210	45
DD62-00084A	35	MLT45	61	W10207397	4	W10721967	82
DD94-01006A	34	MLT50	61	W10209656	11	W10730972	88
DE382	38	MLT55	61	W10209656KIT	11	W10745655	49
DG31-00005A	17	MLT60	61	W10212596	93	W10762263	17
DG32-00002B	19	NEX200828	9	W10212598	93	W10766544	15
DG44-01002A	12	P410	72	W10219643	36	W10779716	4
DG44-01008A	12	P810	73	W10225581	61	W10780045	90
DG44-01009A	12	PA020047	22	W10238100	76	W10780048	90
DG47-00038B	4	PR1	20	W10247306	93	W10820036	84
DG47-00064A	25	PR2	20	W10247710	90	W10820048	90
DG47-00065A	25	PR4	20	W10256908	19	W10822278	60

INDEX

W10822553.....	89	WB30T10047.....	26	WH01X10302.....	80	WR60X10307.....	71
W10836470.....	16	WB30T10074.....	24	WH01X10310.....	83	WR60X10348.....	69
W10837240.....	42	WB30T10078.....	24	WH01X10460.....	83	WR60X162.....	71
W10853654.....	77	WB30T10126.....	26	WH08X10024.....	80	WR60X190.....	71
W10857622.....	12	WB30T10129.....	26	WH08X10050.....	81	WR60X203.....	71
W10861225.....	38	WB30T10130.....	26	WH10X10006.....	85	WR60X26085.....	71
W10869845.....	90	WB30T10132.....	26	WH12X10334.....	84	WR62X10055.....	67
W10876537.....	33	WB30T10133.....	26	WH12X10412.....	85	WR71X10077.....	62
W10876600.....	87	WB30T10135.....	26	WH12X10476.....	86	WR71X2086.....	78
W10913953.....	79	WB30T10136.....	26	WH13X10024.....	94	WR9X355.....	57
W10919003.....	87	WB30T10145.....	26	WH13X10025.....	94	WR9X480.....	60
W11043013.....	77	WB30T10155.....	26	WH13X10026.....	94	WR9X483.....	60
W11088945.....	57	WB30X24111.....	27	WH13X10027.....	94	WR9X489.....	60
W11096267.....	93	WB30X31057.....	24	WH13X10029.....	94	WR9X491.....	58
W11168740.....	93	WB30X31058.....	25	WH13X10037.....	94	WR9X502.....	60
W11168743.....	94	WB31K10012.....	9	WH13X10048.....	94	WR9X520.....	60
W11175771.....	36	WB32K3.....	18	WH13X22314.....	94	WV-1.....	95
W11176265.....	43	WB3X712.....	16	WH13X22720.....	94	WV-2.....	95
W11220230.....	94	WB44K10002.....	6	WH13X25296.....	94	Y700854.....	16
WB02X10700.....	9	WB44K10005.....	4	WH13X26535.....	95	ZC-02.....	52
WB03K10036.....	16	WB44K5009.....	6	WH1X2727.....	81	ZS75.....	52
WB03K10159.....	16	WB44K5012.....	4	WH1X2754.....	83		
WB03K10187.....	16	WB44K5013.....	4	WH23X10028.....	88		
WB03K10202.....	17	WB44T10009.....	6	WH23X10030.....	88		
WB03K10216.....	16	WB44T10010.....	4	WH44X10288.....	85		
WB03K10265.....	16	WB44T10011.....	4	WH49X10042.....	79		
WB03K10302.....	17	WB44T10014.....	4	WIM.....	67		
WB03K10303.....	16	WB44T10104.....	5	WM0612N.....	91		
WB03K10305.....	16	WB44X10009.....	5	WR02X12208.....	57		
WB03T10325.....	16	WB44X10016.....	5	WR07X10131.....	72		
WB03X23020.....	17	WB44X173.....	6	WR09X10042.....	57		
WB06X10596.....	9	WB44X200.....	5	WR09X10049.....	60		
WB13K10043.....	10	WB44X5043.....	5	WR09X10106.....	72		
WB13T10076.....	22	WB44X5082.....	5	WR09X10107.....	72		
WB16K10026.....	6	WB44X5099.....	5	WR13X10020.....	66		
WB17T10006.....	27	WB48T10011.....	19	WR17X11705.....	67		
WB17X5051.....	27	WB48T10063.....	19	WR24X10186.....	65		
WB17X5113.....	27	WB48T10095.....	19	WR24X10228.....	65		
WB19K10008.....	18	WB48X5099.....	19	WR24X10229.....	65		
WB19K10025.....	27	WB6X486.....	9	WR24X10231.....	65		
WB19K12.....	21	WCOIL.....	50	WR24X10236.....	65		
WB19K31.....	21	WD08X10057.....	31	WR24X445.....	65		
WB20K10010.....	29	WD12X271.....	33	WR24X446.....	65		
WB20K10013.....	29	WD15X10003.....	36	WR24X449.....	65		
WB20K10023.....	29	WD15X10011.....	36	WR24X450.....	65		
WB20K10026.....	29	WD21X10261.....	32	WR2X9144.....	65		
WB20K5027.....	29	WD8X227.....	31	WR30X10093.....	67		
WB20K8.....	29	WD8X228.....	31	WR49X392.....	59		
WB20X5071.....	29	WD8X229.....	31	WR50X10025.....	61		
WB21X5287.....	29	WDH6FT.....	83	WR50X10068.....	62		
WB23K5027.....	13	WE01X10160.....	43	WR51X10031.....	59		
WB23M24.....	13	WE01X20374.....	43	WR51X10038.....	59		
WB23X5340.....	20	WE09X20441.....	41	WR51X10053.....	59		
WB24T10022.....	13	WE12X10015.....	38	WR51X10055.....	59		
WB24T10025.....	13	WE12X82.....	38	WR51X442.....	59		
WB24T10027.....	13	WE18X25100.....	44	WR51X443.....	59		
WB24T10029.....	13	WE18X26.....	45	WR55X10025.....	74		
WB24T10058.....	13	WE1M1067.....	40	WR57X10023.....	78		
WB24T10063.....	13	WE1M333.....	40	WR57X10024.....	78		
WB24T10071.....	22	WE1M652.....	43	WR57X10033.....	78		
WB24T10119.....	13	WE1M654.....	44	WR57X10051.....	78		
WB24T10153.....	13	WE1X1263.....	44	WR57X10082.....	78		
WB24T10162.....	13	WE25X205.....	39	WR57X77.....	77		
WB24X25013.....	13	WE3M26.....	39	WR60X10074.....	71		
WB2X1522.....	18	WE49X20697.....	39	WR60X10141.....	71		
WB2X7909.....	2	WE4X444.....	43	WR60X10168.....	68		
WB2X8228.....	27	WE4X739.....	43	WR60X10172.....	71		
WB30K10002.....	24	WE4X750.....	43	WR60X10185.....	71		
WB30K10003.....	24	WF1CB.....	75	WR60X10209.....	68		
WB30T10044.....	26	WF271.....	75	WR60X10220.....	68		
WB30T10045.....	26	WFCB.....	75	WR60X10258.....	68		